



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	3312	821030A15	CARBURETOR (REAR) (BLUE)	1	
1	3312	821030A16	CARBURETOR (FRONT) (BLUE)	1	
2		818892	SPACER-Carburetor Base	2	3
3		818974A 1	LINKAGE ASSEMBLY-Throttle	1	
4		818975	LINK-Connecting	2	
5		818978	LINK-Connecting	1	
6	10	818980	SCREW	1	
7		818979	BELLCRANK-Lower	1	
8	11	35045	NUT (.250-28)	6	
9	10	821282	SCREW (.250-28 x .750)	4	
10	10	92702	SCREW (.250-28 x .875)-Link Arm	2	
11	23	818894	BUSHING-Carburetor Lever	2	
12	12	28426	WASHER	2	
13	11	35045	NUT (.250-28)	1	
14	24	821001	SPRING-Throttle Return	1	
15	11	21825	NUT (.250-28)	1	
16	16	98851	STUD (.250-28 x 1.500)	1	
17	12	29245	WASHER	2	
18	11	56374	NUT (.250-20)	1	
19		818995	BRACKET-Throttle Cable	1	
20	11	35045	NUT (.250-28)	1	
21	11	25168	NUT (.250-28) (THIN)	1	
21	11	21825	NUT (.250-28) (THICK)	1	
22	16	72809	STUD (.250-28 x 1.625)	1	
23	12	21631	WASHER	2	
24	23	31866	SPACER	1	
25	11	56374	NUT (.250-20)	1	
26	32	821120A 1	RAIL ASSEMBLY-Fuel	1	
27	22	817395	FITTING (45 Deg)	1	
28	22	73379	PLUG	1	
29	32	821121	LINE-Fuel-Carb To Rail (Short)	2	
30	32	821122	LINE-Fuel-Carb To Rail (Long-Front)	1	
31	32	821123	LINE-Fuel-Carb To Rail (Long-Rear)	1	
32	54	847630 12	CLAMP-Hose	4	
33	32	821294A 8	HOSE ASSEMBLY (16.00 In.)	2	
34	16	30667	STUD (.250-28 x 3.125)-Flame Arre	2	
35		848623	ARRESTOR-Flame (FRONT)	1	
35		848588	ARRESTOR-Flame (REAR)	1	
36	37	848600	DECAL (FRONT)	1	
36	37	848624	DECAL (REAR)	1	
37	12	96400	WASHER	2	