



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		801763701	TURBO CHARGER	1	808715 REPAIR KIT
1		801763447	TURBO CHARGER	.1	
2	27	801331187	GASKET SET	1.1	
3		801763206	PIPE	1.1	
4		801761273	CONNECTOR	1.1	
5	27	801333462	GASKET	1.1	1.2,3
6	10	809913644	SCREW	2.2	
7	22	801763389	CONNECTOR	1.1	
8	16	801763451	STUD	2.2	
9	27	801333459	GASKET	2.2	1.3,2
10	23	801763450	SPACER	1.1	
11	32	801763778	OIL PIPE	1	
11	32	801763456	OIL PIPE	.1	
12	22	801333464	CONNECTOR	1.1	
13	12	809963354	WASHER	1.1	1.3,2
14	13	809932095	LOCKWASHER	4.4	
15	11	809922087	NUT	2.2	
16		801763449	BRACKET	1.1	
17	10	809912535	SCREW	2.2	
18	10	809919669	SCREW	2.2	
19	13	809932104	LOCKWASHER	2.2	
20	27	801333454	GASKET	1.1	1.3,2
21	16	801333453	STUD	4.4	
22	11	801763448	NUT	4.4	
23		801765010	VENT PIPE	1	
23		801765011	VENT PIPE	.1	
24	10	801763353	BANJO BOLT	1.1	
25	12	809963072	WASHER	2.2	
26	54	801266997	CLAMP	2.2	
27	10	809919926	SCREW	2.2	
28	410	801263264	BANJO BOLT (DOUBLE)	1.1	
29	25	809963130	O-RING	3.3	
30	32	801333456	HOSE	1.1	
31	54	801333457	CLAMP	2.2	
32	27	801331173	GASKET	1.1	1.3,2
33	54	801763272	CLAMP	1.1	
34	12	809931036	WASHER	1.1	
35	11	809922410	NUT	1.1	
36	32	801763455	OIL PIPE	1.1	
37		18833T	EXHAUST PIPE	1.1	
38	10	58540	SCREW (STERN DRIVE)	4.4	