



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		90747A 3	DISTRIBUTOR ASSEMBLY	1		
2		16457A 4	CAP, DISTRIBUTOR	1		
3	10	90926	SCREW, DISTRIBUTOR CAP	4		
4	27	98242	GASKET, DISTRIBUTOR CAP	1		
5		13524A 3	ROTOR	1		
6		42862	SENSOR WHEEL	1		
7	10	11252	SCREW, SENSOR WHEEL	3		
8	87	91019A 3	SENSOR ASSEMBLY	1		
9	10	47618	SCREW, SENSOR	1		
10	12	27736	WASHER, SENSOR SCREW	2		
11	43	813776 1	GEAR, DRIVE	1		
12	17	47617	PIN, DRIVE GEAR	1		
13	27	34486 1	GASKET, DISTRIBUTOR	1		2
14		52185	CLAMP, DISTRIBUTOR TO INTAK	1		
15	10	35169	SCREW, DISTRIBUTOR CLAMP	1		
17	13	26996	LOCKWASHER, DISTRIBUTOR T	2		
18	11	68219	NUT, DISTRIBUTOR TERMINAL	2		
20	84	813720A 2	SPARK PLUG WIRE KIT	1		
21	85	63709A 1	BOOT ASSEMBLY, SPARK PLUG	8		
22	33	59571	SPARK PLUG	8		
23		54676	RETAINER, HIGH TENSION LEAD	2		
24		32783	RETAINER, HIGH TENSION LEAD	2		
25		32784	RETAINER, HIGH TENSION LEAD	2		
26	392	7803A 4	COIL, IGNITION	1		
27		77294	BRACKET, IGNITION COIL	1		
28	10	41408	SCREW, BRACKET (1-1/2")	1		
29	12	30164	WASHER, IGNITION COIL TERMINAL	2		
30	13	26996	LOCKWASHER, IGNITION COIL TERMINAL	2		
31	11	68219	NUT, IGNITION COIL TERMINAL	2		
32	10	59645	SCREW, IGNITION COIL (3/4")	2		
33	13	39107	LOCKWASHER, IGNITION COIL SCREW	2		
34	12	20084	WASHER, IGNITION COIL SCREW	2		
35		63192	RETAINER, HIGH TENSION LEAD	4		
36	10	37612	SCREW, RETAINER (1-1/4") OLI	2		
37	12	25909	WASHER, RETAINER SCREW	2		
38	16	90096A 1	STUD ASSEMBLY NEW DESIGN	2		
39	54	72821	RETAINER WIRE NEW DESIGN	2		
40	10	98260	SCREW	2		
41	13	35048	LOCKWASHER	2		