



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		14957	OIL FILTER	1		
2		92043A 3	BRACKET ASSEMBLY, OIL FILTE	1		
2		44393A 2	BRACKET ASSEMBLY, OIL FILTE	1		
3		78610A 1	BRACKET ASSEMBLY, OIL FILTE	1		
4		32720	ADAPTER	1		
5	32	92357 61	HOSE, OIL - ADAPTER TO BRACK	1		
5	32	92357 28	HOSE, OIL - ADAPTER TO BRACK	1		
6		90783A22	ADAPTER ASSEMBLY, OIL FILTE	1		
7		99889	VALVE, BY-PASS	1		
8		32720	ADAPTER	1		
9	22	37372	PIPE PLUG	1		
10	22	97368	ELBOW, OIL HOSE (90)	2		
11		91830	COVER, ADAPTER	1		
12	27	91892	GASKET, ADAPTER COVER	2		2
13	10	91966	SCREW, OIL FILTER ADAPTER (2	1		
13	10	91967	SCREW, OIL FILTER ADAPTER (2	1		
14		63831A 3	OIL COOLER, ENGINE	1		
15	22	63825	ELBOW, ENGINE OIL COOLER	2		
16		63820 1	BRACKET, OIL COOLER (LONG)	1		
17		56328A 1	BRACKET, OIL COOLER (SHORT)	1		
18	10	60300	SCREW, OIL COOLER BRACKET	2		
19	11	30506	NUT, OIL COOLER BRACKET SCF	2		
20	10	47258	SCREW, OIL COOLER BRACKET	1		
21	13	39107	LOCKWASHER, OIL COOLER BR	1		
22	32	92357 59	HOSE, OIL - OIL COOLER TO BRA	1		
22	32	92357 69	HOSE, OIL - OIL COOLER TO BRA	1		
23	32	92357 28	HOSE, OIL - OIL COOLER TO ADA	1		