



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		60959A	6 TRANSMISSION, V-DRIVE (1.51:1)	1		
1		60960A	6 TRANSMISSION, V-DRIVE (1.99:1)	1		
1		60961A	6 TRANSMISSION, V-DRIVE (2.49:1)	1		
1		60962A	6 TRANSMISSION, V-DRIVE (3.14:1)	1		
2	10	60179	SCREW, TRANSMISSION	6		
3	13	32993	LOCKWASHER, TRANSMISSION	6		
4	32	47516	13 HOSE, OIL COOLER/TRANSMISS	2		
4	32	47516	6 HOSE, OIL COOLER/TRANSMISS	2		
5	87	88031	SWITCH, TEMPERATURE	1		
6		79476A	1 FLANGE ASSEMBLY (1")	OPT.		
6		79476A	2 FLANGE ASSEMBLY (1-1/8")	OPT.		
6		79476A	3 FLANGE ASSEMBLY (1-1/4")	OPT.		
6		79476A	4 FLANGE ASSEMBLY (1-3/8")	OPT.		
6		79476A	5 FLANGE ASSEMBLY (1-1/2")	OPT.		
6		79476A	6 FLANGE ASSEMBLY (1-3/4")	OPT.		
6		79476A	7 FLANGE ASSEMBLY (2")	OPT.		
7	10	60171	SCREW, FLANGE (1-1/4") SEE	2	(Use only with flanges having 1", 1	
7	10	60169	SCREW, FLANGE (3/4") SEE NC	2	(Use only with flanges having 2" sl	
8	10	52498	SCREW, (1-1/2")	4		
9	13	32993	LOCKWASHER, FLANGE SCREW	4		
10	11	22024	NUT, FLANGE SCREW	4		
11	22	47629	ELBOW (90), HOSE	4		
11	22	63824	ELBOW (90 EXTENDED) - HOSE	1		
12	22	88517	ADAPTER, ELBOW	1		
13		63832T	OIL COOLER, TRANSMISSION	1		
14		56328A	1 BRACKET, OIL COOLER (SHORT)	1		
15		63820	3 BRACKET, OIL COOLER (LONG)	1		
16	10	69028	SCREW, OIL COOLER BRACKET	2		
17	12	34931	WASHER, OIL COOLER BRACKET	2		
18	11	30506	NUT, OIL COOLER BRACKET SCF	2		
19		43325	SHIFT LEVER	1		
20	12	20722	WASHER	1		
21	13	26993	LOCKWASHER	1		
22	11	22053	NUT	1		
24		93141A	7 BRACKET, SHIFT CABLE NON-S	1		
25	10	93139	SCREW, SHIFT CABLE (1-1/8")	2		
26	11	20361	NUT, SHIFT CABLE SCREW NOI	2		
27	12	56720	WASHER, SHIFT CABLE SCREW	2		
28	10	33212	SCREW, BRACKET TO TRUNNIO	2		
29	13	32993	LOCKWASHER, BRACKET SCREW	2		
30		98579A	2 BRACKET, SHIFT, SIDE ENTRY	1		