



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-		81719A 4	ALTERNATOR	1		
1	11	42768	NUT	1		
2	13	42769	LOCKWASHER	1		
3		42770	PULLEY	1		
4	23	811865	SPACER	1		
5		811866	FAN	1		
6	23	811867	SPACER	1		
7		811868	BRACKET-Front	1		
8	10	811869	SCREW	3		
9	30	811870	BEARING-Ball	1		
10		811871	RETAINER	1		
11		811872	ROTOR	1		
12		811873	STATOR	1		
13		811874	BRACKET-Rear	1		
14		811875	RECTIFIER	1		
15	10	811876	SCREW	1		
16		811877	MOLD	1		
17	11	811878	NUT	2		
18		811879	CONDENSER	1		
19		811880	MOLD	1		
20	11	811881	NUT	1		
21	10	42773	BOLT-Thru	4		
22		811883	REGULATOR ASSEMBLY	1		
23		811884	BRUSH	2		
24	24	811885	BRUSH SPRING	2		
25	10	811886	SCREW-Set	2		
26		811887	STRAP	1		
27		811888	COVER	1		
28	10	811889	SCREW-Set	1		
29	84	811890	LEAD WIRE	1		
30	84	811891	LEAD WIRE	1		
31	11	811878	NUT	4		