



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		59974	INTAKE MANIFOLD	1		
2	10	37510	BOLT, INTAKE MANIFOLD	16		
3	54	64628	EYE, LIFTING	1		
4	10	34354	SCREW, LIFTING EYE	2		
5		N.S.S.	STUD, GUARD TO INTAKE MANII	4		
6	27	65184	GASKET SET, INTAKE MANIFOLD	1		2
7	22	75983	PIPE PLUG, WATER PUMP/INTA	2		
8	22	66201	CONNECTOR, INTAKE PUMP/INT	2		
9	32	66206	HOSE, BY-PASS - WATER PUMP,	1		
10	54	43510	CLAMP, BY-PASS HOSE	2		
11		17670	WATER PUMP ASSEMBLY	1		
12	27	49110	GASKET, WATER PUMP MOUN	2		2
13	10	32132	SCREW, WATER PUMP TO CYLIN	4		
14		15120T	PULLEY, WATER PUMP (3 GROO	1	(5-1/2 O.D. PULLEY)	
15	57	78200A	BELT, ALTERNATOR DRIVE	1	(5-1/2 O.D. PULLEY)	
14		19692T	PULLEY, WATER PUMP (3 GROO	1	(7" O.D. PULLEY)	
15	57	48122	BELT, ALTERNATOR DRIVE	1	(7" O.D. PULLEY)	
16	13	39107	LOCKWASHER, WATER PUMP P	4		
17		14757	HARMONIC BALANCER (USE 3/8	1		
17		816729	HARMONIC BALANCER (USE 3/8	1		
22		90081T	PULLEY, CRANKSHAFT	1		
23	10	53734	BOLT, PULLEY (3/8-16 X 3")	3		
23	10	75334	BOLT, PULLEY (3/8-24 X 3")	3		
24	13	35048	LOCKWASHER, PULLEY BOLT	3		
25	12	34714	WASHER, PULLEY BOLT	3		
26	13	35048	LOCKWASHER, LIFTING EYE SCF	2		
27	10	14758	BOLT, PULLEY AND HARMONIC I	1		
28	13	14759	LOCKWASHER, PULLEY AND HA	1		
29	12	49103	WASHER, PULLEY AND BALANC	1		
30	10	47277	SCREW, PULLEY TO WATER PU	4		
31		66215	COVER ASSEMBLY, CRANKCASE	1		
32	26	49154	OIL SEAL, CRANKCASE FRONT	1		2
33	27	54529	GASKET, CRANKCASE FRONT EN	1		2
34	10	35366	SCREW, CRANKCASE FRONT EN	10		
35		59966	POINTER, TIMING	1		
-	27	65184A88	GASKET SET	1		