



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		805222A	DISTRIBUTOR ASSEMBLY	1	
2		808483T	CAP	1	
3	10	808491	SCREW	2	
4		808484	ROTOR	1	
5		808485T	SHAFT AND MAGNET	1	
6		808487	RETAINER	1	
7		NSS	SHIELD	1	2
8		811639T	COIL	1	
9		811637T	MODULE	1	
10	10	811638	SCREW	2	
11		811641	POLE PIECE	1	
12	17	808488	PIN	1	
13	12	46350	WASHER	1	
14	12	808489	WASHER	1	
15	43	808490	DRIVE GEAR	1	
16	17	34109	PIN	1	
17	84	817376T	HARNES-DISTRIBUTOR MODUI	1	
18		817378	COIL-IGNITION	1	
19	10	805189	SCREW (3/8-16 X 3/4 IN.)	2	
20	16	90096A	STUD ASSEMBLY	2	
21	54	72821	RETAINER	2	
22		54676	RETAINER (2 WIRE)	2	
23		32783	RETAINER (3 WIRE)	2	
24		32784	RETAINER (4 WIRE)	2	
25	84	816608A68	CABLE KIT-IGNITION (SPARK PLL	1	
26		52185	CLAMP	1	
27	10	805559	SCREW (3/8-16 X 3/4 IN.)	1	
28	27	34486	GASKET-DISTRIBUTOR	1	4
29	33	816336	SPARK PLUG	8	
-	27	802567A98	GASKET SET-ENGINE OVERHAU	1	