



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		818383T	FUEL PUMP	1	
2	27	34213	GASKET	1	2
3	10	34354	SCREW	2	
4	13	35048	LOCKWASHER	2	
5	22	43276	FITTING (90_)	2	
6		89876A 3	BASE ASSEMBLY	1	
7	22	32561	PIPE PLUG	2	
8	22	816133 1	FITTING	1	
9	11	35814	NUT	2	
10	35	807172	FUEL FILTER	1	
11	22	42897	FITTING (STRAIGHT)	1	
12	32	818385T	FUEL LINE, FUEL FILTER TO FUE	1	
13	32	818386T	FUEL LINE, PUMP TO CARBURE	1	
13	32	821498T	FUEL LINE, PUMP TO CARBURE	1	
14	32	73815 67	HOSE, FUEL PUMP TO CARBURE	1	
15		805556T 1	BRACKET	1	