



IMPORTANT

THE ONLY BORG WARNER TRANSMISSION PARTS AVAILABLE FROM MERCURY MARINE ARE THOSE LISTED ON THESE PAGES. IF OTHER BORG WARNER PARTS ARE REQUIRED, THEY MUST BE OBTAINED FROM AN AUTHORIZED BORG WARNER DEALER OR DISTRIBUTOR. CONTACT YOUR MERCURY MARINE REGIONAL SERVICE CENTER FOR THE NAME AND ADDRESS OF THE BORG WARNER DISTRIBUTOR SERVING YOUR AREA.

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		47810A19	TRANSMISSION	1	(1.1:1 RATIO)	
2	10	60179	SCREW (7/16-14 X 3-1/2 IN.)	6		
3	13	32993	LOCKWASHER (7/16 IN.)	6		
4	87	88031	SWITCH-TEMPERATURE	1		
5	32	47516 6	HOSE-OIL	2		
6	22	47629	ELBOW (90 DEG.)	3		
7	22	63835	ELBOW (45 DEG.)	1		
8	22	88517	ADAPTOR	1		
9		79476A 1	FLANGE ASSEMBLY (1 IN.)	OPT		4
9		79476A 2	FLANGE ASSEMBLY (1-1/8 IN.)	OPT		4
9		79476A 3	FLANGE ASSEMBLY (1-1/4 IN.)	OPT		4
9		79476A 4	FLANGE ASSEMBLY (1-3/8 IN.)	OPT		4
9		79476A 5	FLANGE ASSEMBLY (1-1/2 IN.)	OPT		4
9		79476A 6	FLANGE ASSEMBLY (1-3/4 IN.)	OPT		4
9		79476A 7	FLANGE ASSEMBLY (2 IN.)	OPT		4
10	10	60171	SCREW (3/8-16 X 1-1/4 IN.)	2		
10	10	60169	SCREW (3/8-16 X 3/4 IN.)	2		
11	10	805159	SCREW (7/16-20 X 1-1/2 IN.)	4		
12	13	32993	LOCKWASHER (7/16 IN.)	4		
13	11	22024	NUT (7/16-20)	4		
14	16	97477A 3	STUD KIT	1		
15		18351A 1	BRACKET ASSEMBLY	1		
16	16	97477A 3	STUD KIT	1		
17	10	54615	SCREW (1/4-20 X 5/8 IN.)	2		
18	13	26992	LOCKWASHER (1/4 IN.)	2		
19		43325	LEVER-SHIFT	1		
20	12	20722	WASHER	1		
21	13	26993	LOCKWASHER (5/16 IN.)	1		
22	11	22053	NUT (5/16-24)	1		
23		47613	SWITCH-NEUTRAL SAFETY	1		
24		63832T	COOLER-TRANSMISSION OIL	1		
25		56328A 1	BRACKET (SHORT)	1		
26		63820T 1	BRACKET (LONG)	1		
27	10	60300	SCREW (1/4-20 X 3/4 IN.)	2		
28	11	30506	NUT	2		
29	10	47258	SCREW (5/16-18 X 5/8 IN.)	1		
30	13	39107	LOCKWASHER (5/16 IN.)	1		