

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		D807076A1	RESERVOIR/OIL COOLER	1		
2		D807077A1	BRACKET ASSEMBLY	1		
3		18431	PAD	2		
4	10	91903	SCREW	2		
5	12	31263	WASHER	3		
6	54	815504388	CLAMP	2		
7		71587A10	COOLANT RECOVERY SYSTEM	1		
8		71587A11	BOTTLE	1		
9		72058	CAP	1		
10		D807074A1	THERMOSTAT HOUSING	1		
11	DH25	807134	SEAL	1		1
12		99155A 1	THERMOSTAT	1		
13		D807075A1	THERMOSTAT COVER	1		
14	10	29198	SCREW	2		
15	10	98794	SCREW	2		
16	22	818390	DRAIN COCK	1		
17	22	32803	PIPE PLUG	1		
18	27	53045 1	GASKET	1		1
19	54	815504220	CLAMP	AR		
20	D32	807271	HOSE-thermostat by-pass	1		
21	D32	807139	HOSE-reservoir to manifold (STARE	1		
22	32	821415	HOSE-sea pump inlet	1		
23		805135	COUPLING	1		
24	D32	807136	HOSE-water pump to reservoir	1		
25	D32	807141	HOSE-reservoir to manifold (PORT)	1		
26	D32	807137	HOSE-thermostat housing to reserv	1		
27	32	805138	HOSE-water pump to reservoir	1		
28	54	815504232	CLAMP	2		
29	54	815504222	CLAMP	2		
30	23	74756	SPACER	1		

