



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		818383T	FUEL PUMP	1		
2	27	34213	GASKET	1		1
3	10	34354	SCREW	2		
4	13	35048	LOCKWASHER	2		
5	22	43276	FITTING (90 DEGREES)	2		
6		89876A 3	BASE ASSEMBLY	1		
7	22	32561	PIPE PLUG	2		
8	22	816133 1	FITTING	1		
9	11	35814	NUT	2		
10	35	807172	FUEL FILTER	1		
11	22	42897	FITTING (STRAIGHT)	1		
12	32	818385T	FUEL LINE-fuel filter to fuel pump	1		
13	D32	807079T	FUEL LINE-fuel pump to VST	1		
14		805556T 1	BRACKET	1		
15	32	73815 67	HOSE-fuel pump to throttle body	1		
16	54	806617	CLAMP	1		
17	10	47462	SCREW	1		
18	12	22248	WASHER	1		