



| Parts List | | | | | | |
|------------|-------|---------|--------------------------------|-----|---------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| 1 | | 18903T | BRACKET (REAR) | 2 | | |
| 2 | 10 | 806195 | SCREW | 8 | | |
| 3 | 13 | 38829 | LOCKWASHER | 8 | | |
| 4 | 10 | 57357 | SCREW (2-1/4") | 4 | | |
| 5 | 13 | 32993 | LOCKWASHER | 4 | | |
| 7 | 11 | 29553 | NUT | 4 | | |
| 8 | | 66418T | BRACKET (FRONT) | 2 | | |
| 9 | 10 | 68101 | SCREW (1-3/8") | 6 | | |
| 10 | 13 | 35048 | LOCKWASHER | 6 | | |
| 11 | 10 | 57357 | SCREW | 2 | | |
| 12 | 13 | 32993 | LOCKWASHER | 2 | | |
| 13 | 11 | 29553 | NUT | 2 | | |
| 14 | | 66166A | 4 TRUNNION | 4 | | |
| 15 | 13 | 68102 | LOCKWASHER | 4 | | |
| 16 | | 66284A | 2 BASE-engine end (FRONT) | 2 | | |
| 17 | 11 | 20739 | JAM NUT | 4 | | |
| 18 | 14 | 66658 | TAB WASHER | 2 | | |
| 19 | | 816326A | 2 BASE-transmission end (REAR) | 2 | | |
| 20 | 11 | 816331 | JAM NUT | 2 | | |
| 21 | 14 | 66658 | TAB WASHER | 2 | | |
| 22 | 11 | 20739 | NUT | 4 | | |