



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		47810A19	TRANSMISSION (1.1:1 DIRECT D	1		
2	10	60179	SCREW	6		
3	13	32993	LOCKWASHER	6		
4	D32	807291	OIL HOSE	1		
5	22	93190	CONNECTOR	1		
5A	22	807272	ADAPTOR	1		
6	87	88031	TEMPERATURE SWITCH	1		
7	D32	807290	OIL HOSE	1		
8		79476A 1	FLANGE ASSEMBLY (1")	Opt.		
8		79476A 2	FLANGE ASSEMBLY (1-1/8")	Opt.		
8		79476A 3	FLANGE ASSEMBLY (1-1/4")	Opt.		
8		79476A 4	FLANGE ASSEMBLY (1-3/8")	Opt.		
8		79476A 5	FLANGE ASSEMBLY (1-1/2")	Opt.		
8		79476A 6	FLANGE ASSEMBLY (1-3/4")	Opt.		
8		79476A 7	FLANGE ASSEMBLY (2")	Opt.		
9	10	60171	SCREW (1-1/4")	2		
9	10	60169	SCREW (3/4")	2		
10	10	805159	SCREW (1-1/2")	4		
11	13	32993	LOCKWASHER	4		
12	11	22024	NUT	4		
13	16	97477A 3	STUD	1		
14		18351A 1	BRACKET ASSEMBLY	1		
15	16	97477A 3	STUD KIT	1		
16	10	54615	SCREW	2		
17	13	26992	LOCKWASHER	2		
18		43325	SHIFT LEVER	1		
19	12	20722	WASHER	1		
20	13	26993	LOCKWASHER	1		
21	11	22053	NUT	1		
22		47613	SWITCH	1		