



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		805441T 1	BRACKET/LIFTING EYE (REAR)	1		
2	10	47461	SCREW (7/16-14 X 1 IN.)	2		
3	12	22248	WASHER	2		
4		26079A 2	PLATE KIT	1		
5	10	15001	SCREW (#8-16 X 7/8 IN.)	4		
6		97257A 1	SENDER ASSEMBLY-WATER TEM	1		
6		49734A 1	SENDER ASSEMBLY-WATER TEM	OPT	(DUAL STATION)	6
7		815425	SENDER ASSEMBLY-OIL PRESSI	1		
7		37293	SENDER ASSEMBLY-OIL PRESSI	OPT	(DUAL STATION)	6
8	13	26996	LOCKWASHER (#10)	2		
9	11	68219	NUT (#10-32)	2		
10	22	29085	ELBOW-45 DEG.	1		
11		805544T	SENSOR-KNOCK	1		
12	22	805059	BUSHING-REDUCER	1		
13		805218T	SENSOR-COOLANT TEMPERATL	1		