



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		14957	FILTER-OIL	1		
2		817403A 4	BRACKET ASSEMBLY-OIL FILTER	1		
3		38407 1	PLUG-PIPE (1/2-14)	2		
4	22	814822	FITTING-OIL FILTER	1		
5	22	805563	FITTING	2		
6	32	807408	HOSE-BRACKET TO OIL COOLER	1	(IN-LINE TRANSMISSION)	
6	32	807411	HOSE-BRACKET TO OIL COOLER	1	(V-DRIVE TRANSMISSION)	
7	35	818400A 1	ADAPTOR	1		
8	26	42077	SEAL	1		4
9	22	806121	FITTING	1		
10	27	91892	GASKET-ADAPTOR	1		4
11	22	805632	FITTING-ADAPTOR	1		
12		807371T 1	COOLER-ENGINE OIL	1		
13		808043A 1	BRACKET-OIL COOLER	1		
14	12	35462	WASHER	1		
15	11	72008	NUT (1/4-20)	1		
16		807445T	CLAMP	1		
17	32	808017	HOSE-COOLER TO ADAPTOR	1		
18	32	806262 1	HOSE-BRACKET TO ADAPTOR	1	(IN-LINE TRANSMISSION)	
18	32	806178 4	HOSE-BRACKET TO ADAPTOR	1	(V-DRIVE TRANSMISSION)	
-	27	806640A96	GASKET SET-OVERHAUL	1		