



- | | |
|--|---|
| 1 VAPOR SEPARATOR TANK (VST) | 2 THROTTLE BODY |
| 3 DISTRIBUTOR | 4 COIL |
| 5 ELECTRONIC SPARK CONTROL (ESC) MODULE | 6 ASSEMBLY LINE DATA LINK (ALDL) |
| 7 MANIFOLD ABSOLUTE PRESSURE (MAP) SENSOR | 8 MANIFOLD AIR TEMPERATURE (MAT) SENSOR |
| 9 KNOCK SENSOR | 10 IDLE AIR CONTROL (IAC) |
| 11 THROTTLE POSITION SENSOR (TPS) | 12 COOLANT TEMPERATURE SENSOR (CTS) |
| 13 ELECTRONIC CONTROL MODULE (ECM) | 14 FUEL PUMP RELAY (P/N 807057) |
| 15 SYSTEM RELAY | 16 FUEL PUMP FUSE |
| 17 ECM/BATTERY FUSE | 18 ECM/INJECTOR FUSE |
| 19 HARNESS CONNECTOR TO STARTING/CHARGING HARNESS | |
| 20 HARNESS CONNECTOR TO LANYARD STOP SWITCH (OPTIONAL) | |
| 21 HARNESS CONNECTOR FOR DUAL ENGINE DATA LINK CABLE | |
| 22 POSITIVE (+) POWER WIRE TO ENGINE CIRCUIT BREAKER | |

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
-	84	805232A 4	WIRING HARNESS (EFI)	1		