



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		806235A	1 THERMOSTAT HOUSING ASSEM	1		
2	22	32803	PIPE PLUG	2		
3	27	806871	GASKET	1		3
4	27	53045	1 GASKET	1		3
5		807252	2 THERMOSTAT	1		
6	23	806922	SLEEVE	1		
7	10	98794	SCREW	2		
8	54	815504220	CLAMP	AR		2
9	32	17435	79 HOSE-SEA PUMP TO DRIVE UNI	1		
10	32	807404	HOSE-OIL COOLER TO SEA PUM	1		
11	32	807407	HOSE-OIL COOLER TO THERMO:	1		
12	32	807405	HOSE-OIL COOLER TO OIL COOL	1		
13	32	89718	1 HOSE-THERMOSTAT HOUSING	1		
14	54	815504232	CLAMP	2		
15	32	89749	1 HOSE-THERMOSTAT HOUSING	1		
16	32	807201	HOSE-THERMOSTAT HOUSING	1		
17	54	815504222	CLAMP	2		
18		807402T	BRACKET	1		
19		807445T	CLAMP	1		
20	11	72008	NUT	1		
21	10	86750	SCREW	1		
22	13	39107	LOCKWASHER	1		
23		99356A	2 POWER STEERING OIL COOLER	1		
-	27	805396A95	GASKET SET	1		