



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		805441T 1	BRACKET/LIFTING EYE (Rear)	1		
2	10	47461	SCREW (7/16-14 x 1 in.)	2		
3	12	22248	WASHER	2		
4		26079A 2	PLATE KIT	1		
5	10	15001	SCREW (#8-16 x 7/8 in.)	4		
6		97257A 1	SENDER ASSEMBLY-Water Temp	1		
6		49734A 1	SENDER ASSEMBLY-Water Temp	OPT.	(DUAL STATION)	26
7		815425	SENDER ASSEMBLY-Oil Pressure	1		
7		37293	SENDER ASSEMBLY-Oil Pressure	OPT.	(DUAL STATION)	26
8	13	26996	LOCKWASHER (#10)	2		
9	11	68219	NUT (#10-32)	2		
10	22	29085	ELBOW-45 Deg.	1		
11		805544T	SENSOR-Knock	1		
12		805218T	SENSOR-Coolant Temperature	1		
13	22	805059	BUSHING-Reducer	1		
14	87	805605A 1	SWITCH-Oil Pressure	1	AUDIO WARNING SYSTEM	
15	22	64013	REDUCER	1	AUDIO WARNING SYSTEM	
16		816492A 6	ALARM KIT-Audio Warning	1	AUDIO WARNING SYSTEM	
17	84	95084A 9	WIRE ASSEMBLY (Male)	1	AUDIO WARNING SYSTEM	
18	84	95084A10	WIRE ASSEMBLY (Female)	1	AUDIO WARNING SYSTEM	
19	88	79091	FUSE (20 AMP)	1	AUDIO WARNING SYSTEM	