



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	46	807151A12	PUMP ASSEMBLY-SEAWATER	1		
2	46	807151A 7	BODY & COVER	1	TWO PIECE BODY	
3	27	805215 1	GASKET	1	TWO PIECE BODY	
4	10	73275	SCREW (5/16-18 X 2-7/8 IN.)	2	TWO PIECE BODY	
4	10	99347	SCREW (5/16-18 X 3-3/4 IN.)	3	TWO PIECE BODY	
5	12	20084	WASHER	5	TWO PIECE BODY	
6		94916	PLATE-WEAR (OUTER)	1	TWO PIECE BODY	
7	27	94914	GASKET	2	TWO PIECE BODY	
8	46	807151A 7	BODY-WATER PUMP	1	ONE PIECE BODY	
9	25	807149	QUAD RING	1	ONE PIECE BODY	
10	10	807356	SCREW (5/16-18 X 2-5/8 IN.)	2	ONE PIECE BODY	
10	10	74822	SCREW (5/16-18 X 3-1/2 IN.)	3	ONE PIECE BODY	
11	12	814806	WASHER	5	ONE PIECE BODY	
12	47	59362 1	IMPELLER	1		
13		94576	PLATE-WEAR (INNER)	1		
14	25	94288	QUAD RING	1		
15	46	94913A 2	HOUSING ASSEMBLY	1		
16	26	90562	SEAL-OIL	2		
17	30	72961	BEARING-BALL	2		
18		59501A 1	SHAFT	1		
19	53	23720	RING-SNAP	1		
20	26	72785	SEAL-OIL	1		
21		47530	HUB	1		
22		52822T	PULLEY	1		
23	10	47277	SCREW (5/16-24 X 3/4 IN.)	4		
24	13	39107	LOCKWASHER (5/16 IN.)	4		
25	57	13457T	V-BELT	1		
26		15295T	BRACKET	1		
27	10	47461	SCREW (7/16-14 X 1 IN.)	1		
28	10	17965	SCREW (7/16-14 X 3/4 IN.)	1		
29	13	32993	LOCKWASHER (7/16 IN.)	2		
30	12	27025	WASHER	1		
31	13	39107	LOCKWASHER (5/16 IN.)	3		
32	11	21908	NUT (5/16-18)	3		
33		15751T	BRACE	1		
34	10	47461	SCREW (7/16-14 X 1 IN.)	1		
35	13	32993	LOCKWASHER (7/16 IN.)	1		
36	12	30315	WASHER	1		
37	10	35786	SCREW (3/8-24 X 1 IN.)	1		
38	13	35048	LOCKWASHER (3/8 IN.)	1		
39	11	46325	NUT (3/8-24)	1		