



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-		863188A	STEERING SENSOR ASSEMBLY	1		
1		863188T	SENSOR, Steering	1		
2		863175	ADAPTOR, Sensor	1		
3		863174	DRIVER	1		
4	17	863176	PIN	1		
5	12	35044	WASHER, (.281 x .625 x .065 - S	1		
6		863178	BRACKET	1		
7		863177	GUIDE	1		
8	17	863179	CLEVIS PIN, Clevis	1		
9	18	46950	COTTER PIN	1		
10	10	812987	SCREW, (10-24 x 1.25)	2		
11	84	864218	WIRE HARNESS (Fuel Tank)	1		
12	84	864219A	WIRE HARNESS (4 Pin to 4 Pin A	1		
13	84	863931A	HARNESS ASSEMBLY (10 Pin to	1		
N/S	84	884515A	HARNESS, Adaptor	1	(CAN Line)	