



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		90747A27	DISTRIBUTOR ASSEMBLY	1	
1		805185A26	DISTRIBUTOR ASSEMBLY	1	
2		805759A 2	CAP	1	
3	10	90926	SCREW	4	
4	27	805760	GASKET	1	
5		13524A 5	ROTOR/SENSOR WHEEL	1	
6	87	91019A 3	SENSOR ASSEMBLY	1	
7	13	26996	LOCKWASHER	2	
8	11	68219	NUT	2	
9	87	91019A 6	SENSOR ASSEMBLY	1	
10	10	66686	SCREW (1")	1	
10	10	72202	SCREW (1-1/4")	1	
11	43	818807	DRIVE GEAR	1	
12	17	47617	PIN	1	
13	23	90915	BUSHLNG	2	
13A	12	90931	WASHER	2	
14	27	34486 3	GASKET	1	1
15		52185	CLAMP	1	
16	10	806681	SCREW	1	
17	84	816608A61	SPARK PLUG WIRE KIT	1	
18	33	59571	SPARK PLUG	8	
19		54676	RETAINER (2 WIRE)	2	
20		32783	RETAINER (3 WIRE)	2	
21	392	805570A 2	IGNITION COIL	1	
22		77294T	BRACKET	1	
22		65970T 1	BRACKET	1	
23	10	41408	SCREW (1-1/2")	1	
24	13	26996	LOCKWASHER	2	
25	11	68219	NUT	2	
26	10	824941	SCREW (5/16-18 X 3/4")	2	
26	10	92913	SCREW (7/16-14 X 3/4")	2	
28	16	90096A 1	STUD ASSEMBLY	2	
29	54	72821	RETAINER	2	
30	10	98260	SCREW	2	
31	13	35048	LOCKWASHER	2	