



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		48952	WATER TEMP. SWITCH (STAND)	1		
1	87	86080	WATER TEMP. SWITCH (CLOSE	1		
2	13	26996	LOCKWASHER	1		
3	11	45076	NUT	1		
4		38559	PRESSURE SWITCH	1		
5	11	45076	NUT	1		
6		86047A16	BUZZER HOUSING ASSEMBLY	1		
7		86045	TIMER	1		
8		68878A 6	HORN	1		
9	10	69013	SCREW	2		