



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1346	2770	CARBURETOR ASSEMBLY COMF	1		
2	1398	3096	FLOAT ASSEMBLY	1		
3	1398	3098	PIN, FLOAT LEVER	1		
4	1398	3115	SCREW, FLOAT LEVER PIN TO	2		
5	1398	3099	*INLET NEEDLE AND SEAT AS	1		8
6		N.S.S.	*GASKET, INLET NEEDLE AND	1		8
7		N.S.S.	*DIAPHRAGM, STEP-UP ROD	1		8
8		N.S.S.	*SPRING, STEP-UP ROD DIAPH	1		8
9		N.S.S.	*COVER, STEP-UP ROD DIAPHI	1		8
10		N.S.S.	*RETAINER, STEP-UP ROD DIA	1		8
11		N.S.S.	*WASHER, RETAINER- STEP-U	1		8
12	1398	3100	SCREW, IDLE ADJUSTMENT	1		
13	1398	3105	SPRING, IDLE ADJUSTMENT S	1		
14	1398	3133	PLUG, IDLE PORT-CARBURETC	1		
15	1398	3134	WELCH PLUG, FUEL WELL- CA	1		
16	1398	3117	SCREW, THROTTLE ADJUSTIN	1		
17	1398	3104	SPRING, THROTTLE ADJUSTIN	1		
18	1398	3093	SHAFT, CHOKE	1		
19	1398	3092	VALVE, CHOKE-CHOKE SHAFT	1		
20	1398	3119	SCREW, CHOKE VALVE TO CHI	2		
21	1398	3094	LEVER, CHOKE- CHOKE SHAFT	1		
22	1398	3123	ROD, FAST IDLE CONNECTOR	1		
23	1398	3127	WASHER, FAST IDLE CALM CO	1		
24	1398	3102	COLLAR, FAST IDLE CALM	1		
25	1398	3132	CAM, FAST IDLE	1		
26	1398	3125	WASHER, FAST IDLE CAM	1		
27	1398	3114	RETAINER, FAST IDLE CAM TO	1		
28	1398	3129	PISTON, CHOKE	1		
29	1398	3124	LINK, CHOKE PISTON TO LEVE	1		
30	1398	3128	PIN, LINK TO CHOKE PISTON	1		
31	1398	3095	LEVER, CHOKE PISTON	1		
32	1398	3113	SCREW, CHOKE PISTON LEVEL	1		
33		N.S.S.	*GASKET, COIL HOUSING	1		8
34	1398	3131	COIL HOUSING ASSEMBLY	1		
35	1398	3112	SCREW, COIL HOUSING TO CA	3		
36	1398	3108	RETAINER, COIL HOUSING SCI	3		
37	1398	3091	SHAFT AND LOWER ASSEMBL	1		
38	1398	3090	VALVE, THROTTLE- THROTTLE	1		
39	1398	3119	SCREW, THROTTLE VALVE TO	2		
40	1398	3130	"O" RING, THROTTLE SHAFT A	1		
41	1398	3101	WELCH PLUG, CHOKE PISTON	1		