



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		38569	LEVER, THROTTLE - INTERMEDI	1		
2	10	38507	SCREW, THROTTLE LEVER TO I	1		
3	12	20553	WASHER, THROTTLE LEVER SC	1		
4	12	20722	WASHER, THROTTLE LEVER SC	1		
5	12	24676	WASHER, THROTTLE LEVER SC	1		
6	11	20110	NUT, THROTTLE CABLE TO THR	1		
7		38510	LINK ROD, THROTTLE LEVER	1		
8	12	26013	WASHER, LINK ROD	1		
9	18	26953	COTTER PIN, LINK ROD TO THR	1		
10	11	20645	NUT, JAM - LINK ROD	1		
11	11	20110	NUT, LINK ROD TO SLIP LINK	1		
12		38513	SLIP LINK, LINK ROD TO THROT	2		
13	10	38515	BOLT, ANCHOR LINK AND SLIP L	3		
14	11	20110	NUT, ANCHOR LINK AND SLIP LI	3		
15		38514	ANCHOR LINK, LINK ROD TO FRI	1		
16		38511	PLATE THORTTLE - REAR	1		
17	10	20191	SCREW, THROTTLE PLATE TO F	1		
18	13	26995	LOCKWASHER, THROTTLE PLA	1		
19		38533	LINK ROD, REAR THROTTLE PL	1		
20	17	27737	PIN, ROLL - LINK ROD	1		
21	11	20645	NUT, JAM - LINK ROD	1		
22		38512	PLATE THROTTLE - FRONT	1		
23	10	20191	SCREW, THROTTLE PLATE TO F	1		
24	13	26995	LOCKWASHER, THROTTLE PLA	1		
25		38866	RETAINER, SLIP LINK BOLT - TH	1		
26	24	38865	SPRING, THROTTLE RETURN	1		
27		38867	RETAINER, FLAME ARRESTOR F	1		