



		Parts List				
Ref	Class	Part	Description	Qty	Comment	Footnote
1		45657	EXHAUST MANIFOLD	1	SEE NOTE SERIAL 00000000-02	
1		48469	EXHAUST MANIFOLD	1	SEE NOTE SERIAL 02322196-09	
2	22	32802	PLUG, DRAIN-EXHAUST-EXHAU	1		
3		45631	END CAP, EXHAUST MANIFOLD	1		
4	27	45647	GASKET, END CAP	1		
5	10	35388	SCREW, END CAP TO EXHAUST	4		
6	22	46131	ELBOW, END CAP	1		
7	27	46601	GASKET, EXHAUST MANIFOLD T	1		
8	16	37087	STUD, EXHAUST MANIFOLD TO	6		
9	12	46935	WASHER, EXHAUST MAINFOLD	6		
10	11	46603	NUT, EXHAUST MANIFOLD STU	6		
11	22	32715	ELBOW, WATER DISTRIBUTION	1		
12	32	39315A 1	HOSE, THERMOSTAT COVER TC	1		
13	54	38819	CLAMP, HOSE TO THERMOSTAT	2		
14		45623	BLOCK, WATER DISTRIBUTION	1		
15	27	45647	GASKET, WATER DISTRIBUTION	1		
16	22	37372	PLUG, PIPE - WATER DISTRIB	1		
17	10	35388	SCREW, WATER DISTRIBUTION	2		
17	10	45979	SCREW, WATER DISTRIBUTION	1	SERIAL 00000000-02322195	
17	10	47174A 1	SCREW ASSEMBLY, WATER DIS	1	SERIAL 02322196-09999999	
17	10	45981	SCREW, WATER DISTRIBUTION	1		
18	54	34764	EYE, LIFTING - WATER DISTRIB	1		
19	22	46131	ELBOW, WATER DISTRIBUTION	1		
20	32	46716A 1	HOSE, WATER DISTRIBUTION B	1		
21	54	35830	CLAMP, HOSE TO WATER DISTR	1		
22		45864	COVER, INTAKE MANIFOLD	1	SERIAL 00000000-02322195	
23	27	45627	GASKET, INTAKE MANIFOLD COV	1	SERIAL 00000000-02322195	
22		47595	COVER, INTAKE MANIFOLD	1	SERIAL 02322195-09999999	
23	27	49018	GASKET, INTAKE MANIFOLD COV	1	SERIAL 02322195-09999999	
24	10	35388	SCREW, INTAKE MANIFOLD COV	6		
25	22	36382	PLUG, INTAKE MANIFOLD COVE	1		
26	22	22890	CONNECTOR, INTAKE MANIFOLD	1		
27	16	38525	STUD, THROTTLE CABLE TO INT	1		
28	12	24664	WASHER, THROTTLE CABLE ST	2		
29	11	20586	NUT, THROTTLE CABLE STUD	1		
30		45616	ELBOW, MANIFOLD	1	SERIAL 00000000-02322195	
30		48453	ELBOW, MANIFOLD	1	SERIAL 02322196-09999999	
31	22	33198	PLUG, PIPE - MANIFOLD ELBOW	5		
32	27	45649	GASKET, MANIFOLD ELBOW	1		
33	10	45981	SCREW, MANIFOLD ELBOW TO	2		
34	16	21552	STUD, MANIFOLD ELBOW TO ES	2		