



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		848555	ADAPTOR-Remote Oil Filter	1	
2		816163	THERMOSTAT	1	
3	24	816162	SPRING	1	
4	25	47632	O RING	1	
5		816165	COVER-Oil Thermostat	1	
6	53	848571	RING-Snap	1	
7		99889	VALVE-By Pass	1	
8	22	32804	PLUG (.500-14)	1	
9	22	806186	FITTING	1	
10	22	805563	FITTING	1	
11		848556	BRACKET-Oil Adaptor	1	
12	10	99204	SCREW (.437-14 x 1.00)	2	
13	22	805632	CONNECTOR-Oil Filter	1	
14	35	16595	FILTER-Oil	1	
15	12	45175	WASHER (.375 ID)	1	
15	12	45176	WASHER (.437 ID)	1	
16	10	35047	SCREW (.375-16 x 1.250)	1	
16	10	825427	SCREW (.437-14 x 1.250)	1	
17	87	94009	SWITCH-Choke	1	
18	84	848879A	CABLE ASSY	1	(SENDER TO CHOKE) (SER. #0F
18	84	79139A29	CABLE ASSY	1	(SENDER TO COIL) (SERIAL #0F
18	84	848879A	CABLE ASSY	1	(SENDER TO CHOKE & COIL) (S
19	32	848574	HOSE ASSEMBLY (14.500 In.)	1	
20	32	848577	HOSE ASSEMBLY (19.00 In.)	1	
21	32	848575	HOSE ASSEMBLY-Remote Oil To	1	
22	32	848576	HOSE ASSEMBLY-Remote Oil To	1	
23	25	26855	O RING	1	2,5
24	25	32507	O RING	1	2,5
25		814153	ADAPTOR-Oil Filter	1	2
26	12	36533	WASHER	2	2
27	10	67450	SCREW (.312-18 x 2.250)	2	2
28	22	70681	ELBOW (90 Degrees)	1	2
29	22	47630	ELBOW	1	2
30		816482	COOLER-Oil	1	
NS		817043	END CAP	2	1
NS	27	817042	GASKET	2	1
NS	25	814878	O RING	2	1
NS	10	816767	SCREW	2	1
31		12820	BRACKET-Oil Cooler	2	
32		56328A	BRACKET-Oil Cooler	2	
32	10	60200	SCREW (.250-28 x .750)	4	