



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
-	50	17251A 3	STARTER ASSEMBLY	1	(DRIVELINE MODELS)	3
1		79206	HOUSING ASSY	1	(NO LONGER AVAILABLE)	
2	23	33369	BUSHING-Drive End Housing	1		
3		814474	COLLAR-Thrust	1		
4	53	33290	RING-Retaining-Pinion Stop Colla	1		
5		33291	COLLAR-Pinion Stop	1		
6		68608	DRIVE ASSEMBLY-Clutch	1		
7	12	68614	WASHER-Bearing Plate	1		
8	23	71694	BUSHING-Bearing Plate	1		
9		79396	PLATE-Bearing	1		
10	10	79209	SCREW-Bearing	2		
11		68606	ARMATURE	1		
12		NSS	SCREW (#1968396)	4	(SEE NOTE)	7
13		NSS	SHOE (#810601)	4	(SEE NOTE)	7
14		NSS	GROMMET (#1846097)	1	(SEE NOTE)	7
15		NSS	FIELD COIL ASY (#1970467)	1	(SEE NOTE)	7
16		NSS	WASHER-Leather(#1985617)	1	(SEE NOTE)	7
17		NSS	BOLT-Thru (#1939970)	1		7
18		79211	FRAME-Commutator End	1		
19		NSS	SCREW (#1967747)	2		7
19		NSS	SCREW (#443527)	2		7
20		33270	BRUSH-Field Frame	4		
21		33294	SUPPORT	2		
22		33284	HOLDER-Insulated-Field Frame B	2		
23		33283	HOLDER-Field Frame Brush Grou	2		
24	24	33285	SPRING-Field Frame Brush	4		
25		NSS	PIN-Dowel (#1985696)	1		7
26	89	18080	SOLENOID	1		
27		NSS	SCREW-Solenoid (#132255)	2		7
28	24	46889	SPRING-Plunger Return	1		
29		33317	PLUNGER	1		
30		33297	LEVER-Shift	1	(NO LONGER AVAILABLE)	
31	17	79207	PIN-Plunger to Shift Lever	1	(NO LONGER AVAILABLE)	
32	11	26484	NUT (.312-18)-Shift Lever Stud	1		
33	12	68615	WASHER-Shift Lever Stud	1		
34		NSS	STUD-Shift Lever (#1814529)	1		7