



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-		821847A 1	TRANSMISSION ASSEMBLY	1		
1		821847A 5	TRANSMISSION	1		
45		48461	ADAPTOR-Oil Level Gauge Tube	1		
46	25	48462	O RING-Oil Level Gauge Tube	1		
47		48463	TUBE-Oil Level Gauge	1		
48		48464	DIPSTICK-Oil Level	1		
49	25	35276	O RING-Oil Level Gauge	1		
50		48466	BRACKET-Mounting	1		
51	10	34290	SCREW (.250-20 x .625)	2		
52	13	26992	LOCKWASHER (.250)	2		
53		47340A 1	BRACKET ASSY-Trans Mount (POI)	1		
54		35852	MOUNT-Transmission Bracket	1		
55		47334A 2	BRACKET ASSY-Trans Mount (ST)	1		
56		35852	MOUNT-Transmission Bracket	1		
57	10	47462	SCREW (.437-14 x 1.250)	4		
58	13	32993	LOCKWASHER (.437)	4		
59	10	47467	SCREW (.625-18 x 5.500)	2		
60	12	47466	WASHER	4		
61	12	47475	WASHER	2		
62	13	34846	LOCKWASHER	2		
63	12	33171	WASHER	2		
64	11	22339	NUT (.625-18)	2		
65	32	47516 6	HOSE (30.00 In.)-Transmission to O	2		
66	10	60179	SCREW (.437-14 x 3.500)	6		
67	13	32993	LOCKWASHER (.437)	6		
68	12	20722	WASHER-Lever to Transmission	1		
69	13	39107	LOCKWASHER (.312)	1		
70	11	22053	NUT (.312-24)	1		
71	84	88032A 5	CABLE ASSEMBLY (Tan/Blue)	1		
71	84	86322A29	CABLE ASSEMBLY (Black)	1		
72		77054	STA STRAP (14.500 In.)	1		