


MERCURY MARINE



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		64025A	DISTRIBUTOR ASSEMBLY, COM	1	
2	393	4988	CAP, DISTRIBUTOR	1	
-	37	54675	DECAL, DISTRIBUTOR CAP	1	
3		65864	ROTOR	1	
4	10	36046	SCREW, BREAKER AND COND	3	
5	81	64851	CONDENSER	1	
6		64850	BREAKER ASSEMBLY	1	
7	84	64846	LEAD ASSEMBLY, PRIMARY TE	1	
8	54	65783A	CLAMP ASSEMBLYM DISTRIBUTU	2	
9		54205	BUMPER, CLAMP	2	
10	10	21335	SCREW, CLAMP TO DISTRIBUTI	2	
11	13	26996	WASHER, DISTRIBUTOR CLA	2	
12	35	60047A	SCREEN ASSEMBLY, FLAME AF	3	
13	43	58023	GEAR, DRIVE	1	
14	17	58021	PIN, DRIVE GEAR	1	
15	27	58025	"O" RING, DISTRIBUTOR	1	3
16		58258	CLAMP, DISTRIBUTOR TO INTAK	1	
17	10	58259	SCREW, DISTRIBUTOR CLAMP A	1	
18	13	58260	LOCKWASHER, DISTRIBUTOR C	1	
19	84	65796	LEAD ASSEMBLY, DISTRIBUTOR	1	
20		26433	COIL, IGNITION	1	
21		33321	BRACKET, IGNITION COIL MOUN	1	
22	10	33311	SCREW, BRACKET TO IGNITION	1	
23	13	35048	LOCKWASHER, BRACKET SCREW	1	
24	12	30164	WASHER, IGNITION COIL TERMI	2	
25	13	26996	LOCKWASHER, IGNITION COIL T	2	
26	11	20645	NUT, IGNITION COIL TERMINAL	2	
27	10	34613	SCREW, IGNITION COIL ATTACH	1	
28	12	20553	WASHER, IGNITION COIL ATTAC	1	
29	23	60339	SPACER, IGNITION COIL ATTAC	1	
30	84	67957	LEAD ASSEMBLY, HIGH TENSIO	1	
30	84	67957	LEAD ASSEMBLY, HIGH TENSIO	1	
30	84	67957	LEAD ASSEMBLY, HIGH TENSIO	1	
30	84	67957	LEAD ASSEMBLY, HIGH TENSIO	1	
30	84	67957	LEAD ASSEMBLY, HIGH TENSIO	2	
30	84	67957	LEAD ASSEMBLY, HIGH TENSIO	1	
30	84	67957	LEAD ASSEMBLY, HIGH TENSIO	1	
31		47604A	PROTECTOR, SPARK PLUG	8	
32	33	61783	SPARK PLUG (AC#C83T)	8	
33		54676	RETAINER, HIGH TENSION LEAC	2	
33		22782	RETAINER, HIGH TENSION LEAF	2	