



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1356	4642	CARBURETOR ASSEMBLY, COM	1		
2			GASKET, THROTTLE BODY	1		10
3	1396	4646	THROTTLE BODY ASSEMBLY	1		
4	1396	4128	SCREW, THROTTLE BODY ATT	5		
5	1396	4144	LEVER, STOP	1		
6	1396	4131	SCREW, STOP LEVER ATTACH	1		
7	1396	4645	VALVE, THROTTLE	2		
8			SCREW, THROTTLE VALVE AT	4		12
9	1396	4155	LEVER, FUEL PUMP ACTUATIN	1		
10	1396	4133	SCREW, PUMP LEVER ADJUST	1		
11	1396	4105	SPRING, PUMP LEVER ADJUST	1		
12	1396	4089	NUT, PUMP LEVER ADJUSTINC	1		
13			RETAINER, PUMP LEVER	1		12
14		N.S.S.	ROD, PRIMARY(NOT SOLD SEF	1		
15	1396	4143	CAM, FUEL PUMP	1		
16	1396	4135	SCREW, PUMP CAM ATTACHIN	1		
17	1396	4123	SCREW, THROTTLE STOP	1		
18		01396 410	SPRING, THROTTLE STOP SCF	1		
19	1396	4116	VALVE, CHOKE	1		
20			VALVE, PUMP DISCHARGE	1		12
21			NOZZLE, PUMP DISCHARGE	1		12
22			GASKET, DISCHARGE NOZZLE	2		10
23	1396	4138	SCREW, DISCHARGE NOZZLE	1		
24			SEAL, CHOKE LINK	1		10
25	1396	4643	CHOKE SHAFT AND LEVER AS!	1		
26			SCREW, CHOKE VALVE TO CHI	2		12
27	1396	4145	LINK, CHOKE	1		
28			CLIP, CHOKE LINK	1		12
29	1396	4119	SHAFT ASSEMBLY, CHOKE HI	1		
30	1396	4118	LEVER, PICK-UP - FAST IDLE	1		
31	1396	4649	HOUSING ASSEMBLY, CHOKE	1		
32			GASKET, CHOKE HOUSING	2		10
33	1396	4647A 1	NUT ASSEMBLY, VENT - CHOK	1	INCLUDES REFERENCE #34 AN	
36	1396	4130	SCREW, CHOKE HOUSING ATT	3		
37	1396	4121	LINK AND PISTON ASSEMBLY	1		
38	1396	4120	LEVER, CHOKE THERMOSTAT	1		
39	1396	4142	SPACER, CHOKE LEVER	1		
40	1396	4147	LOCKWASHER, CHOKE LEVER	1		
41	1396	4141	NUT, CHOKE LEVER	1		
42	1396	4148	HOUSING ASSEMBLY, THERM	1		
43			GASKET, THERMOSTAT HOUSI	1		10