



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		56174	OIL PUMP ASSEMBLY	1		
2	27	56861	GASKET, OIL PUMP	1		
3	27	56859	GASKET, OIL PUMP SCREEN	1		4
4		56856	SCREEN, OIL PUMP	1		
5	10	56858	SCREW, SCREEN TO OIL PUMP	2		
6	24	56864	SPRING, OIL PUMP RELIEF VALV	1		
7		56865	PLUNGER, OIL PUMP RELIEF VA	1		
8	19	56854	PLUG, OIL PUMP RELIEF VALVE	1		
9		56179	PLATE, OIL PUMP	1		
10	10	56133	SCREW, PLATE TO OIL PUMP (5/	4		
11		56855	SHAFT ASSEMBLY, OIL PUMP	1		
12	53	56860	RING, RETAINING - OIL PUMP	1		
13		56178	ROTOR AND SHAFT, OIL PUMP	1		
14	10	56176	SCREW, OIL PUMP TO CYLINDER	2		
15	13	56177	LOCKWASHER, OIL PUMP SCREW	2		
16		60711	OIL PAN	1	SERIAL 00000000-04170289	
16		75401	OIL PAN	1	SERIAL 04170290-09999999	
17	27	64798	GASKET SET, OIL PAN	1		
18	22	60720	PLUG, DRAIN - OIL PAN	1		
19	27	60721	GASKET, DRAIN PLUG	1		
20	10	56858	SCREW, OIL PAN TO CYLINDER	4		
21	10	60708	SCREW, OIL PAN TO CYLINDER	18		
22		60416	TUBE, OIL LEVEL GAUGE	1	SERIAL 00000000-04170289	
22		71907	TUBE, OIL LEVEL GAUGE	1	SERIAL 04170290-09999999	
23		60606	BRACKET, OIL LEVEL GAUGE	1	SERIAL 00000000-03975694	
23		70717	BRACKET, OIL LEVEL GAUGE	1	SERIAL 03975695-09999999	
24	54	60517	CLAMP, OIL LEVEL GAUGE TUBE	1	SERIAL 00000000-03245667	
25	10	20100	SCREW, CLAMP ATTACHING	1	SERIAL 00000000-03245667	
26	12	26014	WASHER, CLAMP ATTACHING SI	1	SERIAL 00000000-03245667	
27	11	20190	NUT, CLAMP ATTACHING SCREW	1	SERIAL 00000000-03245667	
24	54	61405	CLAMP, OIL LEVEL GAUGE TUBE	1	SERIAL 03245668-09999999	
25	10	21548	SCREW, CLAMP ATTACHING (5/8	1	SERIAL 03245668-09999999	
26	12	29245	WASHER, CLAMP ATTACHING SI	1	SERIAL 03245668-09999999	
27	11	20361	NUT, CLAMP ATTACHING SCREW	1	SERIAL 03245668-09999999	
28	54	61405	CLIP, OIL LEVEL GAUGE TUBE	1		
29	10	20776	SCREW, OIL LEVEL GAUGE TUBE	1		
30		60599	GAUGE, OIL LEVEL (DIPSTICK)	1		