



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		70938	BRACKET, MOUNTING - ENGINE	2	SERIAL 00000000-#4941054	
2	10	37612	SCREW, BRACKET TO ENGINE (	6	SERIAL 00000000-#4941054	
1		79550	BRACKET, MOUNTING - ENGINE	2	SERIAL #4941055-09999999	
2	10	37612	SCREW, BRACKET TO ENGINE (	4	SERIAL #4941055-09999999	
2	10	48424	SCREW, BRACKET TO ENGINE (	2		
3	13	35048	LOCKWASHER, MOUNTING BRA	6		
4		66284	BRACKET, MOUNTING	2		
5	11	20739	NUT, JAM - MOUNTING BRACK	4		
6	13	68102	LOCKWASHER, MOUNTING BRA	2		