



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		77234A	EXHAUST MANIFOLD ASSEMBLY	2		
1		77235A	EXHAUST MANIFOLD ASSEMBLY	2		
1		49545	STUD, EXHAUST MANIFOLD T	8		
2	16	48118	PLUG, EXHAUST MANIFOLD	6		
3	22	32892	PLUG, PIPE-EXHAUST MANIFOL	2		
4	22	33395	GASKET, EXHAUST MANIFOLD T	2		2
5	26	53728	SCREW, EXHAUST MANIFOLD TI	8		
6	10	60252	END CAP/CONNECTOR, EXHAU	4		
7		48043	GASKET, END CAP/CONNECTOF	4		2
8	27	35386	SCREW, END CAP TO MANIFOLC	12		
9	10	73657	SCREW, END CAP TO MANIFOLC	4		
9	10	35386	SCREW, END CAP TO MANIFOLC	14		
9	10	53016	SCREW, END CAP AND FUEL FIL	2		
9A	12	53705	WASHER, END CAP SCREW STE	2		
10		54869	BRACKET, SOLENOID MOUNTINI	1		
11		76351A	EXHAUST ELBOW ASSEMBLY (S	2		
11		76771A	EXHAUST ELBOW ASSEMBLY (IN	2		
12	22	32892	PLUG, PIPE-EXHAUST ELBOW	2		
13	22	33198A	PLUG, EXHAUST ELBOW	8		
14	27	52076	GASKET, ELBOW TO MANIFOLD	4		2
15		60207	PLATE, EXHAUST ELBOW TO M	2		
15		55730	PLATE, EXHAUST ELBOW TO M	2		
16	13	35048	LOCKWASHER, EXHAUST ELBO	8		
17	11	49838	NUT, EXHAUST ELBOW TO EXH	8		
18	22	45084	FITTING, EXHAUST ELBOW	2		