



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		77124A 2	GIMBAL RING ASSEMBLY (SPLIN	1		
1		88343A 2	GIMBAL RING ASSEMBLY (SQUA	1		
2	31	32538	BEARING, ROLLER - GIMBAL R	1		
3	26	32541	OIL SEAL, GIMBAL RING	2		
4	23	39273	SPACER, GIMBAL RING	1		
5	22	69059	FITTING, GREASE - GIMBAL RIT	1		
5A	22	74036	FITTING, GREASE - GIMBAL RINC	2		
6		29359	LUBRICAP, GIMBAL RING GREAS	3		
7		77123	PIN, HINGE - THREADED (WITH I	2		
8		64947	SENDER, DUMMY STARBOARD	1	SEE NOTE	
9	84	70967	HARNESS, DUMMY SENDER ST/	1	SEE NOTE	
10	10	46942	SCREW, HARNESS ATTACHING	2	SEE NOTE	
8		88678A 5	SWITCH ASSEMBLY, TRIM LIMIT	1		
9	84	70968	HARNESS, TRIM LIMIT SWITCH I	1		
10	10	63400	SCREW, HARNESS ATTACHING	2		
11	85	63990	INSULATOR, SWITCH AND SENC	2		
12	10	37978	SCREW, AND SENDER TO GIMB,	4		
13	13	26996	LOCKWASHER, SWITCH AND SE	4		
14		57008	RETAINER, SWITCH AND SENDE	4		
15		66546A 1	STEERING LEVER ASSEMBLY IN	1		
15A	23	52698	SLEEVE, STEERING LEVER IN-	1		
15		88771	STEERING LEVER (IN-LINE ENGI	1		
15		66545	STEERING LEVER (V-8 ENGINES	1		
15		88433	STEERING LEVER (V-8 ENGINES	1		
16		65537	SHAFT, UPPER SWIVEL (SPLINE	1		
16		88302A 2	SHAFT, UPPER SWIVEL (SQUAR	1		
17	53	72413	RETAINING RING, UPPER SWIVE	1	USE WITH SPLINED UPPER SH.	
18	11	25599	NUT, UPPER SWIVEL SHAFT	1		
19	22	32561	PLUG, PIPE - UPPER SWIVEL SH	1	USE WITH SPLINED UPPER SH.	
20	12	85344	WASHER, UPPER SWIVEL SHAF	1		
20	12	32997	WASHER, UPPER SWIVEL SHAF	1		
21	10	32995	SCREW, STEERING LEVER TO U	1		
22	11	79857	NUT, STEERING LEVER TO UPPI	1		
23		68291A 2	STEERING LINK ROD ASSEMBLY	1		
24	23	52698	SLEEVE, STEERING LINK ROD	1		
25	12	20086	WASHER, STEERING LINK ROI	1		
26	12	46132	WASHER, STEERING LINK ROI	1		
27	11	55438	NUT, STEERING LINK ROD IN-	2		
28	18	45882	COTTER PIN, STEERING LINK I	2		
29		78790A 4	STEERING LINK ROD ASSEMBLY	1		
30	10	87728A 1	SCREW ASSEMBLY, LEVER T	1		