



| Parts List |       |        |                              |     |                         |          |
|------------|-------|--------|------------------------------|-----|-------------------------|----------|
| Ref        | Class | Part   | Description                  | Qty | Comment                 | Footnote |
| 1          |       | 88475A | 5 HYDRAULIC PUMP ASSEMBLY (F | 1   |                         |          |
| 1          |       | 93247A | 4 HYDRAULIC PUMP ASSEMBLY (F | 1   |                         |          |
| 1          |       | 79271A | 4 HYDRAULIC PUMP ASSEMBLY (N | 1   |                         |          |
| 2          | 25    | 48171  | "O" RING, HYDRAULIC PUMP T   | 4   |                         |          |
| 3          |       | 48077A | 3 CONTROL VALVE ASSEMBLY     | 1   | NOT USED WITH B-93247A4 |          |
| -          | 25    | 48171  | "O" RING, PUMP TO VALVE (SE  | 4   | NOT USED WITH B-93247A4 |          |
| 4          | 22    | 38609  | PLUG, CONTROL VALVE          | 1   | NOT USED WITH B-93247A4 |          |
| 5          | 10    | 69086  | SCREW, CONTROL VALVE TO H    | 4   | NOT USED WITH B-93247A4 |          |
| 6          | 13    | 26992  | LOCKWASHER, CONTROL VALVE    | 4   | NOT USED WITH B-93247A4 |          |
| 7          |       | 94225A | 1 BRACKET ASSEMBLY, HYDRAUL  | 1   |                         |          |
| 8          | 10    | 26066  | SCREW, HYDRAULIC PUMP TC     | 4   |                         |          |
| 9          | 12    | 20546  | WASHER, HYDRAULIC PUMP E     | 4   |                         |          |
| 10         | 11    | 35814  | NUT, HYDRAULIC PUMP SCRE     | 4   |                         |          |
| 11         | 16    | 87372  | STUD, MOUNTING BRACKET TO    | 3   |                         |          |
| 12         | 11    | 35814  | NUT, MOUNTING BRACKET STU    | 3   |                         |          |
| 13         |       | 88893A | 4 BRACKET ASSEMBLY, FLOOR M  | 1   |                         |          |
| 14         |       | 58491  | BUMPER, RUBBER-PUMP MC       | 2   |                         |          |
| 15         | 10    | 59784  | SCREW, PUMP MOUNTING BRAI    | 6   |                         |          |
| 16         | 12    | 29245  | WASHER, PUMP MOUNTING BR     | 6   |                         |          |
| 17         |       | 45377  | BRACKET, TRANSOM MOUNTIN     | 2   |                         |          |
| 18         | 10    | 24234  | SCREW, HYDRAULIC PUMP TO     | 4   |                         |          |
| 19         | 13    | 39107  | LOCKWASHER, HYDRAULIC PUK    | 4   |                         |          |
| 20         | 11    | 21908  | NUT, HYDRAULIC PUMP SCREW    | 4   |                         |          |
| 21         | 10    | 68298  | SCREW, PUMP MOUNTING BRAC    | 2   |                         |          |
| 22         | 11    | 35304  | NUT, PUMP MOUNTING BRACKE    | 2   |                         |          |