



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		65550A	2 PLATE ASSEMBLY, TRANSOM (I)	1		
1		65545	1 PLATE, TRANSOM (V-8 ENGINES	1		
3	10	37269	2 SCREW, TRANSOM PLATE TO G	2		
4	10	37268	2 SCREW, TRANSOM PLATE TO G	2		
5	13	37272	4 LOCKWASHER, TRANSOM PLAT	4		
6	12	37271	2 WASHER, SQUARE - TRANSOM I	2		
7	10	36289	2 SCREW, TRANSOM PLATE TO FL	2		
8	12	28421	2 WASHER, TRANSOM PLATE SCF	2		
9	23	36290	2 SPACER, TRANSOM PLATE SCR	2		
10	12	32834	2 WASHER, TRANSOM PLATE SCR	2		
11	13	33734A	1 LOCKWASHER, TRANSOM PLAT	2		
12	11	20220	2 NUT, TRANSOM PLATE TO ENGI	2		
13	12	21900	2 WASHER, GIMBAL HOUSING TO	2		
14	11	34087	2 NUT, GIMBAL HOUSING TO TRAI	2		
15	332	35015	1 TUBE, STEERING-IN-LINE-ENGIN	1		
15		75158	1 TUBE, STEERING-V-8 ENGINES-I	1		
16	11	37984	2 NUT, JAM - STEERING CABLE GL	2		
17	12	37985	2 WASHER, STEERING CABLE GUI	2		
18		73679A	2 CABLE ASSEMBLY, SHIFT ACTUA	1		
19		66069A	1 CORE WIRE ASSY, INNER SHII	1		
20	32	38377	1 TUBE, SHIFT ACTUATING CA	1		
21		29880	1 GUIDE, SHIFT ACTUATING CABL	1		
22		20007	1 ANCHOR, SHIFT ACTUATING CAI	1		
23	10	20518	2 SCREW, SET - ANCHOR TO SHIF	2		
24		38473	1 WRAPPING, SHIFT ACTUATING (	1		
25	32	34049	1 TUBE, NYLON - SHIFT ACTUATIN	1		
26		33981	1 SLIDE, SHIFT ACTUATING CABLE	1		
27	10	31700	1 SCREW, SET - SHIFT ACTUATIN(	1		