



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		70861A	GIMBAL HOUSING ASSEMBLY (IN	1		
1		70862A	GIMBAL HOUSING ASSEMBLY (V	1		
2	16	56296	STUD, GIMBAL HOUSING TO T	2		
3	31	32536	BEARING, ROLLER - GIMBAL H	1		
4	26	32911	OIL SEAL, LOWER GIMBAL HOI	2		
5	31	21145	ROLLER BEARING, GIMBAL HO	1		
6	26	97321	OIL SEAL, UPPER GIMBAL HOI	1		
7	22	74036	FITTING, GREASE - GIMBAL HC	2		
8		29359	LUBRICAP, GIMBAL HOUSING (	2		
9	26	88416	SEAL, GREASE - GIMBAL HOUE	1		
10	30	60794A	BEARING ASSEMBLY, BALL -GI	1		
11		61075	TOLERANCE RING, GIMBAL HO	1		
12	10	69707	SCREW, DRIVE - GIMBAL HOUS	4		
13	25	20863	"O" RING, GIMBAL HOUSING	1		
14	25	23145	"O" RING, GIMBAL HOUSING (V	2		
15	16	56766	STUD, HYDRAULIC CONNECTC	2		
16	37	87018	DECAL, GIMBAL HOUSING	1		
17	17	45212	PIN, SWIVEL - GIMBAL HOUSING	1		
18	18	34212	COTTER PIN, RETAINING - LOWE	1		
19	12	32518	WASHER, GIMBAL HOUSING TO	1		
20		55989A	BOLT ASSEMBLY, ANODIC - GIMI	2		
21		55989	ANODIC HEAD, BOLT ASSEMBL	2		
22	12	56085	WASHER, ANODIC BOLT ASSE	2		
23	12	32620	WASHER, GIMBAL HOUSING BOI	2		
24		74639	BELLOWS, SHIFT ACTUATING CA	1		
25	54	38863	CLAMP, ACTUATING CABLE BELL	1		
26	54	31766	CLAMP, SHIFT ACTUATING CABL	1		
27	12	34567	WASHER, GIMBAL HOUSING STI	2		
28	11	34933	NUT, GIMBAL HOUSING STUD	2		
29	32	86907	TUBE, WATER - GIMBAL HOUSIN	1		
29	32	86908	TUBE, WATER - GIMBAL HOUSIN	1		
30	23	28055	BUSHING, RUBBER - WATER TU	1		
31		32517	COVER, WATER TUBE SEALING	1		
32	10	28635	SCREW, WATER TUBE SEALING	2		
33		65533	SEAL, GIMBAL HOUSING TO TRA	1		
34	27	47644	GASKET, HYDRAULIC CONNECT	1		
35		47347	CONNECTOR, HYDRAULIC - GIMI	1		
36	11	35888	NUT, GIMBAL HOUSING TO HYD	2		
37		57322	COVER, RETAINING - GIMBAL HC	1		
38	10	28635	SCREW, COVER TO GIMBAL HOI	2		
39	12	78868	LOCK WASHER, HYDRAULIC CON	2		