



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	435	4352	CAMSHAFT	1	
2	28	37047	KEY, CAMSHAFT	1	
3		46596	PLATE, THRUST - CAMSHAFT	1	
4	10	58554	SCREW, THRUST PLATE TO CYL	2	
5	12	37175	WASHER, THRUST PLATE SCRE	2	
6	43	46576	GEAR, TIMING - CAMSHAFT	1	
7	43	46576	GEAR, TIMING - CAMSHAFT	1	
7		46573	CHAIN, TIMING - CAMSHAFT ANC	1	
8		48097	PLATE, GUIDE - TIMING CHAIN	2	
9	10	58560	SCREW, GUIDE PLATE TO CYLIN	4	
10	12	46610	WASHER, GUIDE PLATE SCREW	4	
11		46598	TENSIONER BLOCK ASSEMBLY,	1	
12	10	58561	SCREW, TENSIONER BLOCK TO	2	
13	12	58575	LOCKWASHER, TENSIONER BL	2	
14		46597	FILTER, TENSIONER BLOCK	1	
15	740	4345	PISTON AND PISTON LINER ASS	4	
16	39	58523A 1	PISTON RING ASSEMBLY	4	
17	27	58515A 1	GASKET ASSEMBLY, CYLINDE	4	
18	616	4349	CONNECTING ROD ASSEMBLY (4	
19	10	58522	SCREW CONNECTING ROD CA	8	
20	11	46547	NUT, CONNNECTING ROD CAP	8	
21	23	58506	BEARING SET (4 PAIRS), CONNE	1	
21	23	58507	BEARING SET (4PAIRS), CONNEC	1	
22	434	4350	CRANKSHAFT	1	
23	28	37116	KEY, CRANKSHAFT	1	
24	43	46545	GEAR, TIMING - CRANKSHAFT	1	
25	23	46544	SLEEVE, CRANKSHAFT TIMING (1	
26	10	58525	SCREW, TIMING GEAR TO CRAN	1	
27	12	46543	WASHER THRUST - TIMING GEA	1	
28		1546554	SHIM, SPACER - MAIN BEARING	AR	
28	15	46553	SHIM, SPACER - MAIN BEARING	AR	
28	15	46552	SHIM, SPACER - MAIN BEARING	AR	
29	25	58508	BEARING SET (5 PAIRS), CRANK:	1	
29	23	58509	BEARING SET (5 PAIRS), CRANK:	1	
30	26	46541	SEAL, REAR MAIN - CRANKSHAF	1	
31	16	46536	STUD, FLYWHEEL TO CRANKSH	7	
32	228	4347	FLYWHEEL ASSEMBLY, CRANKS	1	
33	10	29096	SCREW, ENGINE COUPLING TO	1	
34	231	4037A 1	FLYWHEEL ASSEMBLY, ALTERN	1	
35	11	38270	NUT, FLYWHEEL TO CRANKSHA	7	
36	292	2922	STATOR, ALTERNATOR	1	