



2510

Parts List

| Ref | Class | Part | Description | Qty | Comment | Footnote |
|-----|-------|----------|----------------------------------|-----|---------|----------|
| 0 | 1634 | 2766A 5 | GEAR HOUSING-COMLETE | 1 | | |
| 1 | 1634 | 2766A 1 | GEAR HOUSING (BASIC) | 1 | | |
| 2 | 16 | 36196 | STUD-Gear Housing to Water & | 3 | | |
| 3 | 16 | 56298 | STUD-Gear Housing to Drive S | 2 | | |
| 4 | 31 | 32898 | ROLLER BEARING-Drive Shaft | 1 | | |
| 5 | 45 | 45695A 2 | DRIVE SHAFT ASSEMBLY | 1 | | |
| 6 | 12 | 45698 | WASHER-Drive Shaft | 1 | | |
| 7 | 24 | 20254 | SPRING-Drive Shaft | 1 | | |
| 8 | 17 | 30545 | PIN-Drive Shaft | 1 | | |
| 9 | 43 | 55425 | PINION GEAR | 1 | | |
| 10 | 11 | 30932 | NUT-Pinion Gear to Drive Shaft | 1 | | |
| 11 | 10 | 28634 | SCREW-Gear Housing Grease Fil | 1 | | |
| 12 | 12 | 20260 | WASHER-Rubber-Grease Filler & | 1 | | |
| 13 | | 45686 | SHIFT SHAFT-Lower | 1 | | |
| 14 | 18 | 20233 | COTTER PIN-Shift Shaft | 1 | | |
| 15 | 25 | 25439 | O RING-Shift Shaft Bushing | 1 | | |
| 16 | 23 | 46284A 1 | BUSHING ASSEMBY-Shift Shaft | 1 | | |
| 17 | 26 | 46021 | OIL SEAL-Shift Shaft Bushing | 2 | | |
| 18 | 12 | 31266 | WASHER-Shift Shaft Bushing | 1 | | |
| 19 | 12 | 29395 | WASHER-Shift Shaft | 1 | | |
| 20 | 15 | 45691A 1 | SHIM SET-Drive Shaft Bearing C | AR | | |
| 21 | 31 | 45692A 1 | TAPERED ROLLER BEARING A | 1 | | |
| 22 | | NSS | CUP | 1 | | |
| 23 | 11 | 45690 | NUT-Roller Bearing to Drive Shaf | 1 | | |
| 24 | 25 | 26855 | O RING-Water and Oil Adaptor (L | 1 | | |
| 25 | 27 | 45689 | GASKET-Water and Oil Adaptor | 1 | | |
| 26 | | 45685A 1 | ADAPTOR ASSEMBLY-Water ar | 1 | | |
| 27 | 26 | 38970 | SEAL-Rubber-Water Inlet Tube | 1 | | |
| 28 | 23 | 52928 | SLEEVE-Guide-Water Inlet Tub | 1 | | |
| 29 | 25 | 23145 | O RING-Water and Oil Adaptor | 1 | | |
| 30 | 11 | 30506 | NUT-Water & Oil Adaptor to Gear | 3 | | |