



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		56823	WIRING HARNESS, EXTERNAL	1	
2		26079	PLATE, WIRING HARNESS TO M	1	
3		56731	BRACKET MOUNTING - WIRING I	1	
4	10	46718	SCREW, WIRING HARNESS PLA	4	
5	13	26995	LOCKWASHER, WIRING HARNE	4	
6	10	58510	SCREW, MOUNTING BRACKET T	3	
7	13	46523	LOCKWASHER, MOUNTING BRA	3	
8		56620	BRACKET, MOUNTING - HARNE	1	
9	10	20055	SCREW, BRACKET TO FLYWHEE	1	
10	13	26996	LOCKWASHER, BRACKET SCRE	1	
11		39974	CLAMP, WIRING HARNESS LEA	2	
12	10	22387	SCREW, CLAMP TO MOUNTING I	2	
13	11	53153	NUT, CLAMP SCREW	2	
14	54	39788	CLIP, WIRING HARNESS	1	
15	10	25764	SCREW, WIRING HARNESS CLIP	1	
16		22789	"D" WASHER, WIRING HARNE	1	
17	11	46438	NUT, WIRING HARNESS CLIP SC	1	
18	54	46770	CLAMP, WIRING HARNESS TO V	1	
19	10	29227	SCREW, WIRING HARNESS CLAI	1	
20	11	34388	NUT, WIRING HARNESS CLAMP	1	
21	10	24231	SCREW, WIRING HARNESS LEA	1	
22	11	46438	NUT, WIRING HARNESS LEAD S	1	
23	23	32914	SLEEVE, WIRING HARNESS LEA	1	
24	54	22690	CLIP, WIRING HARNESS ATTACH	1	
25	10	25764	SCREW, WIRING HARNESS CLIP	1	
26	13	26996	LOCKWASHER, WIRING HARNE	1	
27		22789	"D" WASHER, WIRING HARNE	1	
28	11	46438	NUT, WIRING HARNESS CLIP SC	1	
29	50	58059	STARTER MOTOR ASSEMBLY (S	1	
30	10	37388	SCREW, STARTER MOTOR AND	1	
30	10	46197	SCREW, STARTER MOTOR AND	2	
31	11	34933	NUT, STARTER MOTOR AND FL	3	
32		38540	BATTERY CABLE, POSITIVE (REC	1	
33		38539	BATTERY CABLE, NEGATIVE (BL	1	
34	10	38524	SCREW, POSITIVE BATTERY CA	1	
35	13	39107	LOCKWASHER, BATTERY CABLE	1	
36	54	22627	CLAMP, BATTERY CABLE TO BO	2	
37	10	22793	SCREW, BATTERY CABLE CLAMI	2	
38		22789	"D" WASHER, BATTERY CABLE	2	
39		48952	WATER TEMPERATURE SENDEL	1	
40	13	26996	LOCKWASHER, WATER TEMPE	1	