



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-	1351	4263A 1	CARBURETOR ASSEMBLY, COMI	1	SERIAL 03225967-09999999	
-	1351	4263A 2	CARBURETOR ASSEMBLY, COMI	1	SERIAL 00000000-03225968	
1	1397	4336	AIR HORN	1		
2	1397	2256	POWER PISTON ASSEMBLY	1		
3			GASKET, AIR HORN	1		3,4
4	10	33043	SCREW, AIR HORN TO FLOAT	7		
5	10	33048	SCREW, AIR HORN TO FLOAT	1		
6	13	26996	LOCKWASHER, AIR HORN SCF	8		
7	27	58384	GASKET, FUEL FILTER	1		
8	35	53336	FILTER, FUEL INLET	1		
9	24	48143	SPRING, FUEL FILTER	1		
10			GASKET, FUEL INLET NUT	1		3,4
11	1397	4337	NUT, FUEL INLET - AIR HORN	1		
12	1397	2060	FLOAT ASSEMBLY	1		
13	17	33037	PIN, HINGE - FLOAT TO AIR HO	1		
14			CLIP, FLOAT PIN	1		4
15			INLET NEEDLE AND SEAT ASS	1		4
16			GASKET, INLET NEEDLE AND	1		3,4
17	1397	2636	FLOAT BOWL ASSEMBLY	1		
18	1397	2640	VENTURI CLUSTER ASSEMBLY	1		
19			GASKET, VENTURI CLUSTER	1		3,4
20	10	33034	SCREW, VENTURI CLUSTER T	1		
21			GASKET, VENTURI CLUSTER E	1		3,4
22	10	33033	SCREW, VENTURI CLUSTER T	2		
23	13	26995	LOCKWASHER, VENTURI CLU	2		
24			GUIDE, PUMP DISCHARGE - FL	1		
25			SPRING, PUMP DISCHARGE - F	1		
26			BALL, PUMP DISCHARGE - FLO	1		
27			POWER VALVE ASSEMBLY, FLI	1		
28			GASKET, POWER VALVE	1		3,4
29	1397	2447	JET, FLOAT BOWL (STANDARC	2		
30			STRAINER, PUMP INLET	1		
32	10	33047	SCREW, AIR HORN PUMP LEV	1		
33	1397	2054	PUMP SHAFT AND LEVER ASS	1		
34	1397	2051	ROD, PUMP	1		
35			CLIP RETAINER - PUMP ROD	1		4
36			PUMP ASSEMBLY, FLOAT BOW	1		4
37			CLIP, RETAINER - FLOAT BOW	1		4
38			SPRING, PUMP RETURN - FLO	1		
39			BALL, CHECK - PUMP INLET - F	1		
40			GASKET, THROTTLE BODY	1		3,4