



2511

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
0	1634	2766A 5	GEAR HOUSING-COMPLETE	1		
1	1634	2766A 1	GEAR HOUSING (BASIC)	1		
32		36288	SHIFT CAM	1		
33		30625	CAM FOLLOWER	1		
34		30624	SLIDE-Cross Pin	1		
35	24	30622	SPRING-Cam Follower	1		
36	15	30923A 1	SHIM SET-Bearing Cup to Gear F	AR		
37	43	55424	FORWARD GEAR	1		
38	31	30895	ROLLER BEARING-Forward Gea	1		
39	31	30894A 1	TAPERED ROLLER BEARING A	1		
40		NSS	CUP	1		
41	52	34239	CLUTCH	1		
42	17	30632	CROSS PIN-Clutch to Prop Shaft	1		
43	24	30893	SPRING-Cross Pin	1		
44	44	45683	PROP SHAFT	1		
45	43	55428	REVERSE GEAR	1		
46	12	30633	THRUST WASHER-Bearing Carr	1		
47	30	31265	BALL BEARING-Reverse Gear	1		
48	15	29955A 1	SHIM SET-Thrust Washer to Gea	AR		
49	25	29976	O RING-Bearing Carrier	1		
50		45607A 1	BEARING CARRIER ASSEMBLY	1		
51	31	30956	ROLLER BEARING	1		
52	26	30550	OIL SEAL	2		
53	28	30281	KEY-Bearing Carrier	1		
54	12	29957	WASHER-Gear Housing Cover	1		
55		31037	COVER-Gear Housing	1		
56	12	31013	THRUST WASHER-Bearing Carr	1		
57		30581A 1	THRUST HUB AND WASHER A	1		
58	12	29590	CUPPED WASHER	1		
59	12	31211	SPLINED WASHER-Prop Shaft	1		
60	14	31210	TAB WASHER-Prop Shaft	1		
61	11	29594	PROP NUT	1		
62		45684A 1	TRIM TAB	1		
63	10	32470	SCREW-Trim Tab to Gear Housir	1		
64	11	34933	NUT-Drive Shaft Housing to Gear F	1		
65	11	34932	NUT-Drive Shaft Housing to Gear F	1		
0	48	33242A 3	PROPELLER ASSEMBLY	1	(9-1/2 IN. PITCH)	
0	48	35936A 3	PROPELLER ASSEMBLY	1	(11 IN. PITCH)	
0	48	32392A 3	PROPELLER ASSEMBLY	1	(13 IN. PITCH)	
0	48	32390A 3	PROPELLER ASSEMBLY	1	(15 IN. PITCH)	
0	48	32364A 3	PROPELLER ASSEMBLY	1	(17 IN. PITCH)	