



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-	50	58059	STARTER MOTOR ASSEMBLY, C	1		
1		58067	HOUSING, STARTER	1		
2	23	37154	BUSHING, STARTER HOUSING	1		
3		58060	STARTER SOLENOID, STARTER	1		
4	11	58063	NUT KIT, STARTER SOLENOID T	1		
5	11	58071	NUT AND TERMINAL KIT, START	1		
6		58061	ARM, STARTER SOLENOID	1		
7		58064	INSERT, STARTER SOLENOID AI	1		
8	17	58062	PIN ASSEMBLY, SOLENOID ARM	1		
9	19	58066	PLUG, STARTER HOUSING	1		
10		58065	BUMPER, SOLENOID TO CLUTCH	1		
11	23	58068	BUSHING ASSEMBLY, CLUTCH C	1		
12		58069	DRIVE ASSEMBLY, CLUTCH	1		
13	10	58077	BOLT, THRU - STARTER HOUSIN	2		
14	13	58073	LOCKWASHER,, THRU BOLT	4		
15	11	58074	NUT, STARTER HOUSING THRU	4		
16	10	46653	SCREW, STARTER FIELD COIL	4		
17		58075	ARMATURE	1		
18	23	58070	BUSHING, ARMATURE SHAFT	1		
19	12	58072	WAHSER KIT, ARMATURE	1		
20		58075	FIELD COIL ASSEMBLY	1		
21		58076	BRUCH KIT, STARTER (POSITIVE	1		
22	24	46662	SPRING KIT, STARTER BRUSH	1		
23		46658	BAND, STARTER MOTOR	1		
24	11	46659	NUT, STARTER MOTOR BAND S	1		
25	23	37154	BUCHING, END COVER	1		