



| Parts List |       |         |                              |     |                          |          |
|------------|-------|---------|------------------------------|-----|--------------------------|----------|
| Ref        | Class | Part    | Description                  | Qty | Comment                  | Footnote |
| -          | 1351  | 4263A 1 | CARBURETOR ASSEMBLY, COMI    | 1   | SERIAL 03225967-09999999 |          |
| -          | 1351  | 4263A 2 | CARBURETOR ASSEMBLY, COMI    | 1   | SERIAL 00000000-03225968 |          |
| 1          | 1397  | 4336    | AIR HORN                     | 1   |                          |          |
| 2          | 1397  | 2256    | POWER PISTON ASSEMBLY        | 1   |                          |          |
| 3          |       |         | GASKET, AIR HORN             | 1   |                          | 3,4      |
| 4          | 10    | 33043   | SCREW, AIR HORN TO FLOAT     | 7   |                          |          |
| 5          | 10    | 33048   | SCREW, AIR HORN TO FLOAT     | 1   |                          |          |
| 6          | 13    | 26996   | LOCKWASHER, AIR HORN SCF     | 8   |                          |          |
| 7          | 27    | 58384   | GASKET, FUEL FILTER          | 1   |                          |          |
| 8          | 35    | 53336   | FILTER, FUEL INLET           | 1   |                          |          |
| 9          | 24    | 48143   | SPRING, FUEL FILTER          | 1   |                          |          |
| 10         |       |         | GASKET, FUEL INLET NUT       | 1   |                          | 3,4      |
| 11         | 1397  | 4337    | NUT, FUEL INLET - AIR HORN   | 1   |                          |          |
| 12         | 1397  | 2060    | FLOAT ASSEMBLY               | 1   |                          |          |
| 13         | 17    | 33037   | PIN, HINGE - FLOAT TO AIR HO | 1   |                          |          |
| 14         |       |         | CLIP, FLOAT PIN              | 1   |                          | 4        |
| 15         |       |         | INLET NEEDLE AND SEAT ASS    | 1   |                          | 4        |
| 16         |       |         | GASKET, INLET NEEDLE AND     | 1   |                          | 3,4      |
| 17         | 1397  | 2636    | FLOAT BOWL ASSEMBLY          | 1   |                          |          |
| 18         | 1397  | 2640    | VENTURI CLUSTER ASSEMBLY     | 1   |                          |          |
| 19         |       |         | GASKET, VENTURI CLUSTER      | 1   |                          | 3,4      |
| 20         | 10    | 33034   | SCREW, VENTURI CLUSTER T     | 1   |                          |          |
| 21         |       |         | GASKET, VENTURI CLUSTER      | 1   |                          | 3,4      |
| 22         | 10    | 33033   | SCREW, VENTURI CLUSTER T     | 2   |                          |          |
| 23         | 13    | 26995   | LOCKWASHER, VENTURI CLU      | 2   |                          |          |
| 24         |       |         | GUIDE, PUMP DISCHARGE - FL   | 1   |                          |          |
| 25         |       |         | SPRING, PUMP DISCHARGE - F   | 1   |                          |          |
| 26         |       |         | BALL, PUMP DISCHARGE - FLO   | 1   |                          |          |
| 27         |       |         | POWER VALVE ASSEMBLY, FLI    | 1   |                          |          |
| 28         |       |         | GASKET, POWER VALVE          | 1   |                          | 3,4      |
| 29         | 1397  | 2447    | JET, FLOAT BOWL (STANDARC    | 2   |                          |          |
| 30         |       |         | STRAINER, PUMP INLET         | 1   |                          |          |
| 32         | 10    | 33047   | SCREW, AIR HORN PUMP LEV     | 1   |                          |          |
| 33         | 1397  | 2054    | PUMP SHAFT AND LEVER ASS     | 1   |                          |          |
| 34         | 1397  | 2051    | ROD, PUMP                    | 1   |                          |          |
| 35         |       |         | CLIP RETAINER - PUMP ROD     | 1   |                          | 4        |
| 36         |       |         | PUMP ASSEMBLY, FLOAT BOW     | 1   |                          | 4        |
| 37         |       |         | CLIP, RETAINER - FLOAT BOW   | 1   |                          | 4        |
| 38         |       |         | SPRING, PUMP RETURN - FLO    | 1   |                          |          |
| 39         |       |         | BALL, CHECK - PUMP INLET - F | 1   |                          |          |
| 40         |       |         | GASKET, THROTTLE BODY        | 1   |                          | 3,4      |