



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		55613A 1	EXHAUST MANIFOLD ASSEMBLY	1	SERIAL 00000000-03225967	
1		55613A 3	EXHAUST MANIFOLD ASSEMBLY	1	SERIAL 03225968-09999999	
2	22	56308	PLUG, PIPE - EXHAUST MANIFOLD	3		
3	16	49545	STUD, EXHAUST MANIFOLD TO	4		
4	22	46131	ELBOW, EXHAUST MANIFOLD	1		
5	27	56204	GASKET, EXHAUST MANIFOLD T	1		
6	16	56509	STUD, EXHAUST MANIFOLD TO	5		
7	12	26825	WASHER, EXHAUST MANIFOLD	5		
8	11	46793	NUT, EXHAUST MANIFOLD STU	5		
9	37	57471	DECAL, EXHAUST MANIFOLD (9C	1		
10		55514	END CAP, EXHAUST MANIFOLD	1		
11		55517	END CAP, EXHAUST MANIFOLD	1		
12	27	48043	GASKET, END CAP TO MANIFOLD	2		
13	54	34764	LIFTING EYE	1		
14	10	53016	SCREW, LIFTING EYE AND END	1		
14	10	53576	SCREW, END CAP TO EXHAUST	3		
14	10	25038	SCREW, END CAP TO EXHAUST	4		
15		55513A 3	EXHAUST ELBOW ASSEMBLY	1		
16	22	56308	PLUG, PIPE - EXHAUST ELBOW	4		
16	22	32802	PLUG, PIPE - EXHAUST ELBOW	1		
17	32	58616A 1	TUBE ASSEMBLY, EXHAUST ELE	1		
18	27	52076	GASKET, EXHAUST ELBOW	1		
19	12	20553	WASHER, EXHAUST ELBOW STU	4		
20	11	23161	NUT, EXHAUST ELBOW STU	4		
21		56040	BELLOWS, EXHAUST ELBOW TC	1		
22	54	33683	CLAMP, BELLOW TO ELBOW ANI	4		
23		55612	HOUSING, THERMOSTAT AND M	1		
24	27	56203	GASKET, THERMOSTAT HOUSIN	1		
25	27	47590	GASKET, THERMOSTAT COVER	1		
26		47594	THERMOSTAT	1		
27		55516	COVER, THERMOSTAT HOUSIN	1		
28	10	53512	SCREW, THERMOSTAT COVER	2		
29	32	56505	HOSE, THERMOSTAT COVER TC	1		
30	54	38426	CLAMP, HOSE TO THERMOSTAT	2		
31	22	47841	FITTING, THERMOSTAT HOUSIN	1		
32	32	56730	HOSE, THERMOSTAT TO CHECK	1		
33	54	38819	CLAMP, HOSE THERMOSTAT HC	2		
34	21	57790A 2	CHECK VALVE, WATER DISTRIBI	1		
35	22	54107	FITTING, CHECK VALVE TO CYLI	1		
36	32	46716A 1	HOSE, CHECK VALVE TO FLYWH	1		
37	54	38819	CLAMP, HOSE TO CHECK VALVE	2		