



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		848555T	ADAPTOR-Oil Thermostat Housing	1		
2		99889	VALVE-Bypass	1		
3	22	805632	CONNECTOR-Oil Filter	1		
4	35	16595T 1	FILTER-Oil	1		
5	22	32804	PLUG-Pipe (.500-14)	1		
6	22	847720 13	FITTING (Straight)	6		
7	10	99204	SCREW (.437-14 x 1.00)	2		
8		848556 2	BRACKET	1		
9	12	856774	WASHER	2		
10	10	65210	SCREW (.375-16 x 1.00)	2	(Bracket To Cylinder Head)	
11		816163	THERMOSTAT-Oil	1		
12	24	816162	SPRING	1		
13	25	47632	O RING	1		2
14		816165 1	COVER-Oil Thermostat	1		
15	53	848571	RING-Retaining	1		
16	32	821284A15	HOSE ASSEMBLY (18.88 Inches)	1	(Adaptor To Filter Out)	
17	32	821284A16	HOSE ASSEMBLY (13.38 Inches)	1	(Filter To Adaptor Return)	
18	32	821284A20	HOSE ASSEMBLY (23.18 Inches)	1	(Filter To Cooler Out)	
19	32	821284A18	HOSE ASSEMBLY (19.50 Inches)	1	(Return Cooler To Filter)	
20	32	821284A17	HOSE ASSEMBLY (23.88 Inches)	1	(Cooler To Cooler)	
21	16	72742	STUD (.312-18/.312-24 x 1.090)	1		
22	12	56720	WASHER	1		
23	11	826709 11	NUT (.312-24)	1		
24		849324	BRACKET-Oil Cooler	1		
25	54	815504352	CLAMP	2		
26	32	53461 70	HOSE	1	(Water Pump To Cooler) (48.00 Inc	
27	54	18076 6	CLAMP	4		
28	22	32802 2	PLUG-Pipe (.125-27 Brass)	1		
29	32	47516 6	HOSE ASSEMBLY (30.00 Inches)	2		
30		849115	COOLER	1	(Transmission And Power Steering	
31	22	47629	FITTING (90 Degree)	2		
32	22	70834	FITTING (Straight)	1		
33	32	64346	HOSE	1	(Cooler To Flywheel Housing)	
34	10	67450	SCREW (.312-18 x 2.250)	2		5
35	12	36533	WASHER (Copper)	2		2,5
36		814153 1	ADAPTOR-Oil Filter	1		5
37	25	32507	O RING	1		2,5
38	25	26855	O RING	1		2,5
-	27	840277A 1	GASKET SET-Engine Overhaul	1		