



SUPERCHARGER ASSEMBLY

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		818728	SUPERCHARGER ASSEMBLY	1	(See Supercharger Components S	
2	11	817618	NUT (.437-20)	8		
3	12	45176	WASHER	12		
4	27	822125	GASKET	2	(Intake To Intercooler And Interco	2
5		818729	INTERCOOLER ASSEMBLY	1		
6	12	846673	WASHER	8		
7	10	816742	SCREW (.250-20 x 1.250)	8		
8		847816	CORE-Intercooler	1		
9	27	841398	GASKET-Core Cover	2		2
10	25	822368	O RING	1		2
11	22	849090	FITTING (45 Degree)	1		
12	22	847719	FITTING (Straight)	1		
13		818716	SPACER-Idler Pulley Bracket	2		
14		818714	BRACKET-Idler Pulley	1		
15		818786A	IDLER PULLEY ASSEMBLY	1		
16	31	818791	BEARING	1		
17	53	818792	RING-Snap	1		
18	12	818789	WASHER	1		
19	10	818790	SCREW (.625-18 x 3.750)	1		
20	57	818725	BELT-Supercharger	1		