

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
NS	90	848991010	MANUAL	1	(Operation/Maintenance/Warranty	
NS	90	848992010	MANUAL	1	(Installation)	
NS	90	849250R 1	GUIDE	1	(Hi Performace Boat Operation)	
NS	90	883862	CATALOG-Parts	1	(Engine)	
NS	90	853693	CATALOG-Parts	1	(Transoms And Drives)	

NO IMAGE