



NOTE: FOR CONTINUITY CIRCUIT COMPONENTS, SEE THE "CONTINUITY KIT" SECTION.
 NOTE: ACCESS HOLE PLUG KIT (22-88847A1) CONTAINS ALL NECESSARY PARTS TO ALLOW REMOVAL OF SWIVEL SHAFT WITHOUT REMOVING GIMBAL HOUSING.

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		43881A14	GIMBAL HOUSING	1		
2	16	56296	STUD (7/16 X 4-3/4 IN.)	4		
3	16	818834	STUD (7/16 X 4-1/4 IN.)	4		
4	23	98357 1	BUSHING-LOWER	1		
5	26	41607 1	SEAL-OIL	1		
6	23	98356	BUSHING-UPPER	1		
7	22	74036	FITTING-GREASE (1/4-28)	1		
8	19	77633	LUBRICAP	1		
9	26	88416	SEAL-OIL	1		
10	30	60794A 4	BEARING ASSEMBLY	1		
11		61075	RING-TOLERANCE	1		
12		41802	O-RING	1		
13	16	56766	STUD (1/4 X 1-3/8 IN.)	2		
14		43713	SEAL	1		
15	22	73379	PLUG-PIPE (1/4-18)	1		
16	32	41672 1	TUBE-WATER	1		
17	23	816599 1	BUSHING	1		
18		41673	COVER	1		
19	10	28636	SCREW (1/4-20 X 3/4 IN.)	2		
20	17	99353	PIN-LOWER SWIVEL	1		
21	18	54929	PIN-COTTER	1		
22	12	32518	WASHER	1		
23		74639	BELLOWS-SHIFT CABLE	1		
24	54	38863	CLAMP	1		
25	54	815504320	CLAMP	1		
26	12	34567	WASHER	8		
27	11	34933	NUT (7/16-20)	8		
28		98825A 4	MANIFOLD ASSEMBLY	1		
29	27	98823 1	GASKET	1		
30	13	78968	LOCKWASHER (1/4 IN.)	2		
31	11	13438	NUT (1/4-28)	2		
32		821631A 1	ANODIC PLATE ASSEMBLY	1		
33		12077	SEAL	1		
34	27	99506 1	GASKET	1		
35	10	86885	SCREW (1/4-20 X 1-1/2 IN.)	2		
36	13	78968	LOCKWASHER (1/4 IN.)	2		
-	22	88847A 1	ACCESS HOLE PLUG KIT	1		